

# GigaVUE-HC2 Hardware Installation Guide

*GigaVUE-OS 5.7.00*

## COPYRIGHT

Copyright © 2019 Gigamon Inc. All Rights Reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without Gigamon's written permission.

## TRADEMARK ATTRIBUTIONS

Copyright © 2019 Gigamon Inc. All rights reserved. Gigamon and the Gigamon logo are trademarks of Gigamon in the United States and/or other countries. Gigamon trademarks can be found at [www.gigamon.com/legal-trademarks](http://www.gigamon.com/legal-trademarks). All other trademarks are the trademarks of their respective owners.

## DOCUMENT REVISION – 7/31/19

# Contents

---

<b>Chapter 1 Introducing the GigaVUE-HC2</b> .....	<b>7</b>
About the GigaVUE H Series and TA Series .....	8
GigaVUE-HC2 Overview .....	8
Introducing the GigaVUE-HC2 Chassis .....	9
GigaVUE-HC2 Chassis – Front View .....	9
GigaVUE-HC2 Chassis – Rear View .....	10
Air Flow Direction .....	11
AC- and DC-Powered GigaVUE-HC2 .....	11
GigaVUE-HC2 Control Cards .....	12
GigaVUE-HC2 Control Card Version 2 (HC2 CCv2) .....	13
GigaVUE-HC2 Modules .....	14
Module Numbering .....	15
PRT-HC0-X24 Module .....	16
PRT-HC0-Q06 Module .....	17
PRT-HC0-C02 Module .....	18
Module Status LEDs .....	19
Port Status LEDs .....	19
PRT-HC0-C02 Notes and Rules .....	19
100G Chassis Mode for PRT-HC0-C02 .....	20
Module Placement of PRT-HC0-C02 .....	20
GigaTAP Modules .....	22
TAP-HC0-D25AC0 Module .....	22
TAP-HC0-D25BC0 Module .....	23
TAP-HC0-D35CC0 Module .....	23
TAP-HC0-G100C0 Module .....	24
Using the TAP-HC0-G100C0 Module for Copper Bypass .....	24
Using TAP-HC0-G100C0 Module for Gigamon Resiliency for Inline Protection .....	25
Bypass Combo Modules .....	26
10Gb Bypass Combo Modules .....	26
40Gb Bypass Combo Module .....	30
GigaSMART Rear Module .....	33
Hot Swap Button LED .....	33
GigaSMART Front Module .....	34
Module Status LEDs .....	35
Port Status LEDs .....	35
Hot Swap Button .....	35

<b>Chapter 2 GigaVUE-HC2 Installation Roadmap</b> .....	<b>37</b>
First Steps – Getting Unpacked, Racked, Installed and Connected .....	37
Next Steps .....	38
<b>Chapter 3 Assembling the GigaVUE-HC2 Node</b> .....	<b>39</b>
Unpacking the GigaVUE-HC2 Shipment .....	39
Rack-Mounting the GigaVUE-HC2 Chassis .....	40
Safety Precautions .....	40
Rack-Mounting Procedure .....	41
Front-Mount GigaVUE-HC2 .....	41
Four-Post Rack Mounting .....	42
Installing Power Modules in the GigaVUE-HC2 Chassis .....	43
Installing the Cable Management Trays in the GigaVUE-HC2 Chassis ...	44
Rack Ear for Cable Management .....	45
Installing Control Card in the GigaVUE-HC2 Chassis .....	46
Avoid Electrostatic Damage! .....	46
Control Card Installation Procedure .....	46
Installing the Rear GigaSMART Module .....	48
Removing the Rear GigaSMART Module .....	48
Backing Up Running Configuration .....	49
Removing the Front GigaSMART Module .....	49
Installing and Removing Modules Procedure .....	51
Hot Swapping Modules .....	51
Module Installation Procedure .....	52
Module Removal and Replacement Procedure (Hot Removal) .....	53
Replacing a Module with the Same Type of Module .....	53
Replacing a Module with a Different Type of Module .....	53
Next Steps .....	53
<b>Chapter 4 Basic GigaVUE H Series Connections and Configuration</b> .....	<b>55</b>
Grounding the GigaVUE-HC2 Chassis .....	56
Connecting Power to the GigaVUE-HC2 .....	57
Removing a Power Module .....	58
Connecting -48V DC Power Supplies .....	59
Fan Trays .....	60
Checking Fan Status .....	60
Configuring SNMP Notification .....	60
Replacing a Fan Tray .....	60
Connecting Serial Console and Mgmt Ports .....	62
Configuring Basic GigaVUE H Series Settings .....	62
Access the Command-Line Interface over the Console Port .....	62
Changing the Console Port's Speed .....	64
Run the Jump-Start Script .....	64
Need to Change Any Settings? .....	66
Configure Modules and Enable Ports .....	67
Command-Line Basics .....	69
Command-Line Modes .....	69

Entering Commands in the CLI .....	71
Command-Line Syntax – Entering Commands .....	72
Configure Mode Syntax .....	72
Paging through CLI Output .....	73
The Basic Commands .....	74
Completing the Initial GigaVUE H Series Setup .....	77
Enter the Configure Command-Line Mode .....	78
SSH, Telnet, or Both? .....	78
Advantages of SSH2 .....	79
Changing Host Keys .....	79
Enabling the GigaVUE H Series Web Server .....	80
Connecting to the GigaVUE H Series Node from H-VUE .....	80
Initial User Account Configuration .....	82
Configuring the GigaVUE H Series Host Name .....	84
Configuring GigaVUE H Series Time Options .....	84
Setting Time Manually .....	84
Performing One-Time NTP Server Synchronization .....	84
Using NTP Time Server for Clock Synchronization .....	85
Configuring Automatic Email Notifications .....	86
Using a Custom Banner .....	87
Saving Changes .....	88
<b>Chapter 5 Connecting GigaVUE-HC2 Ports .....</b>	<b>89</b>
Transceiver—Rules and Notes .....	89
BiDi Optics Considerations .....	90
Transceiver Installation Instructions .....	90
Installing Transceivers .....	90
Removing Transceivers .....	91
Fiber TAP Specifications .....	91
Bypass Combo Module Specifications .....	91
Module Transceiver Support .....	92
Cabling .....	94
MPO/MTP 12 Position Fiber Cable for Use with SR4 Transceivers .....	94
Connecting GigaVUE-HC2 Module Ports .....	94
Enabling Modules and Ports .....	95
Setting Port Parameters Manually .....	96
Forcelinkup and Enabling/Disabling Ports .....	97
<b>A GigaVUE-HC2 Specifications .....</b>	<b>99</b>
Physical Dimensions and Weight .....	99
Power Requirements .....	100
Environmental Specifications .....	100
Standards and Protocols .....	101
Compliance .....	101
Safety .....	101
Emissions .....	101
Class A Information Technology Equipment (ITE) .....	102
Immunity .....	102

Environmental .....	102
Security .....	102
Warranty .....	103
<b>B Replacing a Control Card .....</b>	<b>105</b>
<b>C Upgrading to HC2 CCv2 .....</b>	<b>111</b>
Standalone Node .....	111
Node in Out-of-Band Cluster .....	114
Node in Inband Cluster .....	116
<b>D Console Port Signaling and Cabling .....</b>	<b>119</b>
<b>E NEBS Level 3 Compliance .....</b>	<b>121</b>
Installation Instructions GigaVUE-HC2 .....	121
Intrabuilding or Intra-connection .....	121
Intrabuilding Ports (RJ45) .....	122
Class A2 Voltage Accessibility .....	122
Class B Voltage Accessibility .....	122
Equipment Grounding Systems .....	122
Communication Equipment Grounding .....	122
Bonding of Battery Return (BR) Input Terminals .....	123
Connections .....	123
Input AC/DC Voltage .....	123
Commercial Power Ports .....	123
Maintenance .....	124
<b>F Additional Sources of Information .....</b>	<b>125</b>
Documentation .....	125
Documentation Feedback .....	127
Contacting Technical Support .....	127
Contacting Sales .....	127
The Gigamon Community .....	127

## Introducing the GigaVUE-HC2

---

This chapter introduces the GigaVUE-HC2 of Gigamon Traffic Platform nodes, describes their features and functions, and provides an orientation to the physical layout of the GigaVUE-HC2.

Refer to the following sections for details:

- [About the GigaVUE H Series and TA Series on page 8](#)
- [GigaVUE-HC2 Overview on page 8](#)
- [Introducing the GigaVUE-HC2 Chassis on page 9](#)
- [GigaVUE-HC2 Control Cards on page 12](#)
- [AC- and DC-Powered GigaVUE-HC2 on page 11](#)
- [GigaVUE-HC2 Modules on page 14](#)
  - [Module Numbering on page 15](#)
  - [PRT-HC0-X24 Module on page 16](#)
  - [PRT-HC0-Q06 Module on page 17](#)
  - [PRT-HC0-C02 Module on page 18](#)
  - [GigaTAP Modules on page 22](#)
    - [TAP-HC0-D25AC0 Module on page 22](#)
    - [TAP-HC0-D25BC0 Module on page 23](#)
    - [TAP-HC0-D35CC0 Module on page 23](#)
    - [TAP-HC0-G100C0 Module on page 24](#)
  - [Bypass Combo Modules on page 26](#)
    - [10Gb Bypass Combo Modules on page 26](#)
    - [40Gb Bypass Combo Module on page 30](#)
  - [GigaSMART Rear Module on page 33](#)
  - [GigaSMART Front Module on page 34](#)

## About the GigaVUE H Series and TA Series

The GigaVUE Visibility Platform delivers 1Gb/10Gb/40Gb/100Gb support. The GigaVUE H Series and TA Series include the following models that run GigaVUE-OS:

- GigaVUE-HC1
- GigaVUE-HC2
- GigaVUE-HC3
- GigaVUE-TA10
- GigaVUE-TA40
- GigaVUE-TA100
- GigaVUE-TA100-CXP
- GigaVUE-TA200
- Certified Traffic Aggregation White Boxes

## GigaVUE-HC2 Overview


The GigaVUE-HC2 delivers unprecedented switching capacity, port density, and modularity in a mid-sized 2RU footprint. This node broadens the GigaVUE H Series portfolio offering multi-functional capabilities such as internal TAPs, port modules, and a variety of GigaSMART options. The node is appropriate for concentration points requiring up to 96 ports in a single location.

### GigaVUE-HC2


- **2RU Footprint**
- **Four Module Slots (Bays)**
- **Internal Control Card**
- **Dedicated Cluster Management Port**
- **Supports all GigaVUE-HC2 Modules**
- **All ports, excluding BPS ports, of same type and speed can be used to create GigaStream.**

GigaVUE-HC2

Front



Rear





## Introducing the GigaVUE-HC2 Chassis

The fully-assembled GigaVUE-HC2 chassis consists of a 2RU, rack-mountable, 19in-wide chassis with management, network, and tool ports at the front and power connections, fans, and access to the control card at the rear. GigaSMART is available on both the front and rear. [GigaVUE-HC2 Chassis – Front View on page 9](#) summarizes the bays and components at the front and [GigaVUE-HC2 Chassis – Rear View on page 10](#) summarizes the rear of the GigaVUE-HC2 chassis.

**NOTE:** The GigaVUE-HC2 chassis arrives from the factory with power supplies, control card, and all modules separately. Refer to [Unpacking the GigaVUE-HC2 Shipment on page 39](#) for assembly instructions.

### GigaVUE-HC2 Chassis – Front View




Figure 1-1: Front View of the GigaVUE-HC2 Chassis

## GigaVUE-HC2 Chassis – Rear View




Figure 1-2: Rear View of the GigaVUE-HC2 Chassis

Table 1-1: GigaVUE-HC2 Chassis Bays and Components

Bays on the GigaVUE-HC2 Chassis	
<b>Module Bays</b>	There are four module bays. They are numbered from 1 to 4, starting with top left, then bottom left; top right, then bottom right.
<b>Cable Management Tray</b>	The GigaVUE-HC2 provides two optional cable management trays at the left and right side of the node for secure routing of cables to GigaVUE ports. Installation of the cable management tray requires a special mounting bracket. Refer to <a href="#">Rack-Mounting Procedure on page 41</a> for details.
Rear Components on the GigaVUE-HC2 Chassis	
<b>Power Modules</b>	<p>The GigaVUE-HC2 includes two separate power supplies for installation at the rear of the node. Each power module can independently operate the entire GigaVUE-HC2 for 1+1 system redundancy. Separate AC and DC power units are available.</p> <p>Refer to <b>Power Configurations on page 100</b> for information on power characteristics of the GigaVUE-HC2.</p>
<b>Control Card</b>	<p>The GigaVUE-HC2 includes a control card installed inside the unit, accessible from the rear of the chassis, behind the fan unit.</p> <p>The control card provides switching and processing resources for the entire chassis. It also controls the Mgmt port and console port on the front of the node for network and local administrative access to the GigaVUE-OS command-line interface (CLI).</p> <p>Starting in software version 4.6, GigaVUE-HC2 Control Card version 2 (HC2 CCv2) is available.</p> <p>Refer to <a href="#">GigaVUE-HC2 Control Cards on page 12</a> for more information.</p>
<b>Fan Trays</b>	The fan trays installed at the rear of the node provide system cooling.

## Air Flow Direction

The air flow direction is from the front of the GigaVUE chassis to the rear. The rear-mounted fans pull air from the front to the back of the chassis. For environments with hot/cold aisles, install the chassis so the intake air at the front of the chassis is cold.


## AC- and DC-Powered GigaVUE-HC2

Gigamon provides both AC- and DC-powered versions of the GigaVUE-HC2. Both models support the same control modules and can be populated with the modules of your choice. Refer to [Installing Power Modules in the GigaVUE-HC2 Chassis on page 43](#) for information on connecting DC power supplies.

# GigaVUE-HC2 Control Cards

The control card is the heart of the GigaVUE-HC2, providing both processing and switching fabric resources, as well as user access to the CLI via the Mgmt/console ports.

Starting in software version 4.6, GigaVUE-HC2 Control Card version 2 (HC2 CCv2) is available.



## Status LEDs

Shows the status of the control module, including whether the module has power (PWR), whether the module is successfully booted and ready for operations (RDY)

- PWR - Illuminates when power is present.
- RDY - Module booted and ready for operations
- M/S - Master/Slave: Illuminated when it is a master in a cluster; it is off when it is a normal or standby node in a cluster; it is either off or illuminated when it is a standalone node, depending on whether or not it was ever the master node in a cluster previously
- Fan - Illuminated when fans are operating
- Rear - Illuminated when rear GigaSMART is ready

## PTP Port (eth1)

Connection for PTP grandmaster clock source. After configuring an IP profile for the PTP port, you can enable PTP in the CLI with the "ptp enable" command. Refer to the *GigaVUE-OS CLI Reference Guide* for details.

## Cluster Management Port (eth2)


Provides cluster support, with a dedicated out-of-band network connection for cluster management traffic.

## Management Port (eth0)

Standard 10/100/1000 RJ45 Ethernet port supports remote connections to the GigaVUE-OS using Telnet/SSH. Green LED shows link status; amber LED shows activity.

## Console Port

Use the console port for serial terminal connections to the GigaVUE-OS. Unless you requested custom factory settings, the serial settings are 8N1, 115,200 bps. The GigaVUE-HC2 node includes a standard console cable.



## Lock Status LEDs

Illuminates when the node has synchronized successfully with the corresponding time source:  
-- PPS (In) – Illuminates when the node has synchronized with a pulse-per-second source over the PPS input selected with the "timestamp pps-source" command

Figure 1-3: GigaVUE-HC2 Management Ports

## GigaVUE-HC2 Control Card Version 2 (HC2 CCv2)

GigaVUE-HC2 Control Card version 2 (HC2 CCv2) provides the following benefits:

- Enables 100Gb on the PRT-HC0-C02 module. Refer to [PRT-HC0-C02 Module on page 18](#).
- Supports 16k map rules.
- Supports all GigaVUE-HC2 modules, front and rear.
- Has the same ports and status LEDs as shown in [Figure 1-3 on page 12](#).

HC2 CCv2 is field-replaceable. To upgrade an existing control card to an HC2 CCv2, use the procedure in [C Upgrading to HC2 CCv2 on page 111](#).

The HC2 CCv2 is identified by the following part number label printed on the control card: 132-00C2-400.

**NOTE:** The software version on the HC2 CCv2 must be 4.6 or higher.

## GigaVUE-HC2 Modules

With a wide variety of interchangeable modules and more than a terabit of switching capacity, GigaVUE-HC2 nodes are ready to grow with your needs. Separate modules let you add the ports you need:

<b>PRT-HC0-X24</b>	<ul style="list-style-type: none"> <li>• <b>Twenty-four</b> 10Gb/1Gb (SFP+, SFP+ Copper/SFP) Ports</li> </ul>	<i><a href="#">PRT-HC0-X24 Module on page 16</a></i>
<b>PRT-HC0-Q06</b>	<ul style="list-style-type: none"> <li>• <b>Six</b> 40Gb (QSFP+) Ports</li> </ul>	<i><a href="#">PRT-HC0-Q06 Module on page 17</a></i>
<b>PRT-HC0-C02</b>	<ul style="list-style-type: none"> <li>• <b>Two</b> 100Gb (QSFP28) Ports</li> </ul>	<i><a href="#">PRT-HC0-C02 Module on page 18</a></i>
<b>TAP-HC0-D25AC0</b>	<ul style="list-style-type: none"> <li>• <b>Twelve</b> TAP SX/SR (50/125) Fiber TAP</li> </ul>	<i><a href="#">TAP-HC0-D25AC0 Module on page 22</a></i>
<b>TAP-HC0-D25BC0</b>	<ul style="list-style-type: none"> <li>• <b>Twelve</b> TAP SX/SR (62.5/125) Fiber TAP</li> </ul>	<i><a href="#">TAP-HC0-D25BC0 Module on page 23</a></i>
<b>TAP-HC0-D35CC0</b>	<ul style="list-style-type: none"> <li>• <b>Twelve</b> TAP LX/LR Fiber TAP</li> </ul>	<i><a href="#">TAP-HC0-D35CC0 Module on page 23</a></i>
<b>TAP-HC0-G100C0</b>	<ul style="list-style-type: none"> <li>• <b>Twelve</b> TAP 1Gb Copper TAP</li> </ul>	<i><a href="#">TAP-HC0-G100C0 Module on page 24</a></i>
<b>BPS-HC0-D25A4G</b>	<ul style="list-style-type: none"> <li>• Bypass Combo Module, GigaVUE-HC2, with <b>Four</b> SX/SR (50/125µm) BPS Port Pairs and <b>Sixteen</b> SFP and SFP+ Port Cages</li> </ul>	<i><a href="#">10Gb Bypass Combo Modules on page 26</a></i>
<b>BPS-HC0-D25B4G</b>	<ul style="list-style-type: none"> <li>• Bypass Combo Module, GigaVUE-HC2, with <b>Four</b> SX/SR (62.5/125µm) BPS Port Pairs and <b>Sixteen</b> SFP and SFP+ Port Cages</li> </ul>	<i><a href="#">10Gb Bypass Combo Modules on page 26</a></i>
<b>BPS-HC0-D35C4G</b>	<ul style="list-style-type: none"> <li>• Bypass Combo Module, GigaVUE-HC2, with <b>Four</b> LX/LR BPS Port Pairs and <b>Sixteen</b> SFP and SFP+ Port Cages</li> </ul>	<i><a href="#">10Gb Bypass Combo Modules on page 26</a></i>
<b>BPS-HC0-Q25A28</b>	<ul style="list-style-type: none"> <li>• Bypass Combo Module, GigaVUE-HC2, with <b>Two</b> SR4 (50/125µm) BPS Port Pairs and <b>Eight</b> SFP and SFP+ Port Cages</li> </ul>	<i><a href="#">40Gb Bypass Combo Module on page 30</a></i>
<b>SMT-HC0-R</b>	<ul style="list-style-type: none"> <li>• GigaSMART Rear Module</li> </ul>	<i><a href="#">GigaSMART Rear Module on page 33</a></i>
<b>SMT-HC0-X16</b>	<ul style="list-style-type: none"> <li>• GigaSMART Front Module with <b>Sixteen</b> 10Gb SFP and SFP+ Port Cages</li> </ul>	<i><a href="#">GigaSMART Front Module on page 34</a></i>

Modules are hot-swappable and can be installed in any of the available front bays in a GigaVUE-HC2 node. **However, refer to [Module Removal and Replacement Procedure \(Hot Removal\)](#) on page 53 for instructions – you must follow a specific procedure when removing modules to preserve node stability.**

## Module Numbering

Modules use standard conventions for identifying network/tool ports, both on the modules themselves, as well as in the CLI:

<b>100Gb Ports</b>	<ul style="list-style-type: none"><li>Numbered with a leading <b>C</b>. For example, the PRT-HC0-C02 includes 100Gb ports <b>C1</b> and <b>C2</b>.</li></ul>
<b>40Gb Ports</b>	<ul style="list-style-type: none"><li>Numbered with a leading <b>Q</b>. For example, the PRT-HC0-Q06 includes 40Gb ports <b>Q1</b> to <b>Q6</b>.</li></ul>
<b>10Gb Ports</b>	<ul style="list-style-type: none"><li>Numbered with a leading <b>X</b>. For example, the PRT-HC0-X24 includes 10Gb/1Gb ports <b>X1</b> to <b>X24</b>, the bypass combo modules include 10Gb ports <b>X1</b> to <b>X16</b>.</li></ul>
<b>1Gb Ports</b>	<ul style="list-style-type: none"><li>Numbered with a leading <b>G</b>.</li></ul>

**NOTE:** When referring to ports in the CLI, the format is **box ID/slot ID/port ID**. For example, **1/1/x6** refers to box 1, slot 1, port X6.


- GigaVUE-HC2:** Slots (bays) are numbered 1-4 from left upper, left lower, right upper to right lower.

**NOTE:** The port labels on the module faceplate use upper-case C, Q, X, and G characters to identify ports. However, the CLI uses lowercase notation to refer to ports (for example, c1, q1, x1, and g1).

## PRT-HC0-X24 Module

The PRT-HC0-X24 module provides a total 240Gb of connectivity with line rate on-board switching across twenty-four 10Gb SFP+ ports. All ports in the PRT-HC0-X24 module can be used as network, tool, inline tool, or stack-link ports.


For details about the supported transceiver, cable type, fanout, inline ports, and clusters, refer to “*GigaVUE-OS Compatibility and Interoperability Matrix*”.



### Status LEDs

Status LEDs show the status of the module:

- The RDY LED turns GREEN once the module has been configured in CLI or GUI, indicating it is ready to use. Until then, it is RED.
- The PWR LED is illuminated when the module is receiving power from the chassis.



### 10Gb/1Gb Ports

PRT-HC0-X24 provides 24 10Gb/1Gb ports, each labeled with an X prefix.

The 10Gb ports support SR/LR/ER/LRM optical and direct attach copper SFP+ transceivers. You can also use 1Gb SX/LX SFPs in the 10Gb ports for 1Gb support.

Copper 1Gb SFPs can also be used in the 10Gb ports. However, they will only provide 1Gb speeds, not 10/100Mb.

### GigaStream

The PRT-HC0-X24 module supports GigaStream functionality.


Figure 1-4: PRT-HC0-X24 Module



# PRT-HC0-Q06 Module


The PRT-HC0-Q06 module provides a total 240Gb of connectivity with line-rate on-board switching across six 40Gb QSFP+ ports. All ports in the PRT-HC0-Q06 module can be used as network, tool, inline tool, or stack-link ports. In particular, 40Gb ports are useful as stack-links to carry traffic between GigaVUE H Series nodes operating in a cluster or to receive aggregated input from a matching 40Gb port on a GigaVUE TA Series aggregation node. The PRT-HC0-Q06 module can connect to all GigaVUE nodes that support 40Gb through a 40Gb stack-link, using SR4, ESR4, and LR4 optics. However, you cannot connect this module with PRT-HC0-C02 on GigaVUE-HC2.

For details about the supported transceiver, cable type, fanout, inline ports, and clusters, refer to “GigaVUE-OS Compatibility and Interoperability Matrix”.



### Status LEDs

Status LEDs show the status of the module:  
– The RDY LED is GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.  
– The PWR LED is illuminated when the module is receiving power from the chassis.



### 40Gb Network/Tool Ports

PRT-HC0-Q06 provides 6 separate QSFP+ based network/tool ports for 40Gb traffic. The PRT-HC0-Q06 provides 6 X 40Gb ports.

The 40Gb ports support QSFP+ transceivers. For supported transceivers, refer to *BiDi Optics Considerations* on page 90 for 40Gb) (q) ports.

### GigaStream

The PRT-HC0-Q06 module supports GigaStream functionality.

Figure 1-5: PRT-HC0-Q06 Module

## PRT-HC0-C02 Module



The PRT-HC0-C02 module provides two 100Gb QSFP28 ports, supporting 100Gb monitoring and aggregation.

The PRT-HC0-C02 is installed in the front module bays of the GigaVUE-HC2.

Before installing the PRT-HC0-C02 module, the GigaVUE-HC2 node must be running software version 4.6 or higher.

For details about the supported transceiver, cable type, fanout, inline ports, and clusters, refer to “*GigaVUE-OS Compatibility and Interoperability Matrix*”.

**NOTE:** The PRT-HC0-C02 can only be used on a GigaVUE-HC2 node equipped with GigaVUE-HC2 Control Card version 2 (HC2 CCv2). Refer to [Figure 1-6 on page 18](#).



### Status LEDs

Status LEDs show the status of the module: The Rdy LED is GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.

The Pwr LED is GREEN when the module is receiving power from the chassis.

### 100Gb Ports

PRT-HC0-C02 provides two 100Gb ports.

The ports are designated as C1 and C2, from left to right as viewed from the front.

The 100Gb ports have four LEDs: L1 to L4.

L1 is the LED for 100Gb.

L2 to L4 are AMBER (reserved for future use).

The L1 LED has the following states:

GREEN indicates the link is up.

AMBER indicates the port is disabled.

OFF indicates the port is administratively enabled, but the link is down.

Figure 1-6: PRT-HC0-C02 Front Module

## Module Status LEDs

The module status LEDs are as follows:

- Rdy is the Ready LED. It has the following states:
  - RED indicates the system is booting up
  - GREEN indicates the system is ready
- Pwr is the Power LED. It has the following state:
  - GREEN indicates the module is receiving power

## Port Status LEDs

The 100Gb port status LED, L1, has the following states:

- Off indicates the port is administratively enabled, but the link is operationally down
- GREEN indicates the link is operationally up
- AMBER indicates the port is disabled

The 100Gb port status LEDs, L2 to L4, have the following state:

- AMBER indicates reserved for future use

## PRT-HC0-C02 Notes and Rules

Keep in mind the following notes and rules when using the PRT-HC0-C02 module:

PRT-HC0-C02 Notes	
Control Card Version 2 Required	The PRT-HC0-C02 can only be used on a GigaVUE-HC2 node equipped with GigaVUE-HC2 Control Card version 2 (HC2 CCv2).
Transceivers	For details about the supported transceiver, cable type, and connectivity specifications, refer to <i>"GigaVUE-OS Compatibility and Interoperability Matrix"</i> .
Maximum PRT-HC0-C02 Modules Per Chassis	The maximum number of PRT-HC0-C02 modules per chassis is four, supporting up to eight 100Gb ports. <b>NOTE:</b> If all modules in the chassis are 100Gb, there are no 10Gb ports with which to connect tools. Refer also to <i>100G Chassis Mode for PRT-HC0-C02 on page 20</i> and <i>Module Placement of PRT-HC0-C02 on page 20</i> .
Network, Tool, Hybrid, or Stack-Link Port	The 100Gb ports on the PRT-HC0-C02 can be used as a network, tool, or hybrid ports. They cannot be used as stack-link ports.
Inline Ports	The 100Gb ports can be configured as inline network or inline tool ports, supporting 100Gb logical bypass. For details about the supported inline ports, refer to <i>"GigaVUE-OS Compatibility and Interoperability Matrix"</i> .
Map Rules	The PRT-HC0-C02 supports 16k (16383) map rules per module. The maximum number of rules per map is 4k (4096).

## 100G Chassis Mode for PRT-HC0-C02

GigaVUE-HC2 nodes equipped with Control Card version 2 (HC2 CCv2) AND 100Gb modules, PRT-HC0-CO2, require a chassis mode of **100G** to be configured in software.

The default mode for all platforms is **normal**. To change the mode to **100G**, first remove the existing configuration from the chassis, then configure the mode. For example:

```
(config) # no chassis box-id 1
(config) # chassis box-id 1 mode 100G
```

When the GigaVUE-HC2 has a PRT-HC0-CO2 module installed and the mode is configured to **100G**, the port count is limited to 42 ports on the columns of the node. Modules in bays 1 and 2 are the left column, and modules in bays 3 and 4 are the right column. Refer to [Figure 1-1 on page 9](#) for a view of the front of the chassis. Also, refer to [Module Placement of PRT-HC0-C02 on page 20](#) for best practices when **100G** mode is configured.

Starting in software version 4.7.01, you can optionally specify the **100G** mode on either the left column or the right column of the node. For example:

```
(config) # chassis box-id 1 mode 100G left
```

When the left column is configured for **100G** mode, install the PRT-HC0-CO2 module in the bays in the left column. The left column is subject to the 42 port limitation. The right column will not be limited to 42 ports, but you will not be able to install the PRT-HC0-CO2 module in the bays in the right column.

Conversely, when the right column is configured for **100G** mode, install the PRT-HC0-CO2 module in the bays in the right column. The right column is subject to the 42 port limitation. The left column will not be limited to 42 ports, but you will not be able to install the PRT-HC0-CO2 module in the bays in the left column.

## Module Placement of PRT-HC0-C02

With 42 ports per column, the best practices for placement of PRT-HC0-CO2 modules are as follows:

- Place PRT-HC0-CO2 modules in bays 1 and 3 or bays 2 and 4. This uses 2 ports on each column, leaving 40 ports for the other module in the column.
- Use only one 24-port module per column. The 24-port modules are: PRT-HC0-X24, Bypass Combo Modules (BPS-HC0-D25A4G, BPS-HC0-D25B4G, BPS-HC0-D35C4G), and TAP modules (TAP-HC0-D25AC0, TAP-HC0-D25BC0, TAP-HC0-D35CC0, TAP-HC0-G100C0).

Refer to [Figure 1-7 on page 21](#) for examples of incorrect and correct module placement when **100G** mode is configured.



*Figure 1-7: Module Placement of PRT-HC0-CO2, 100G Mode*

Refer to [Figure 1-8 on page 21](#) for an example of module placement when **100G left** mode is configured.



C02 in left column    48 ports in right column allowed

*Figure 1-8: Module Placement of PRT-HC0-CO2, 100G Left Mode*

## GigaTAP Modules

GigaTAP modules provide internal TAP (Tapping Access Point) capabilities to passively copy optical traffic flowing between two external sources (typically, switches, routers, and servers) into the GigaVUE-HC2 node.


These modules contains 24 fiber ports, set up in pairs to allow bidirectional traffic to continue to flow between the original sources and destinations. Since there are 12 sets of port pairs, the modules provide for 12 TAPs. An internal optical splitter passively copies the traffic to the backplane at line speeds. Even in the event of a power loss in the chassis, traffic will continue to pass between the original source and destination.

Unlike an external TAP, an internal TAP has no external ports for the copied traffic; as the traffic goes directly to the backplane of the unit. This maximizes the use of the ports on the module to provide maximum TAP density. This also prevents unauthorized users from attaching a local Sniffer to capture and see the packets without permission. Thus, only users properly logged into the system gain access to sensitive information.

For internal transceiver and loss summary specifications, refer to [Fiber TAP Specifications on page 91](#).

### TAP-HC0-D25AC0 Module


The GigaTAP TAP-HC0-D25AC0 module provides 12 SX/SR TAP connections to be used as network ports running over 50/125 micron fiber. This module has 24 ports, enabling 12 TAPs. Each port pair is arranged one above the other providing bidirectional traffic to flow between two nodes. Internally, a splitter passively copies traffic for use with flow maps.



#### Status LEDs

Status LEDs show the status of the module:

- The RDY LED is GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.
- The PWR LED is illuminated when the module is receiving power from the chassis.




#### Port and TAP Numbering

Ports and TAP combinations are labeled on the module faceplate and run sequentially from left to right.

Figure 1-9: TAP-HC0-D25AC0 Module

## TAP-HC0-D25BC0 Module


The GigaTAP TAP-HC0-D25BC0 module provides 12 SX/SR TAP connections to be used as network ports running over 62.5/125 micron fiber. This module has 24 ports, enabling 12 TAPs. Each port pair is arranged one above the other providing bidirectional traffic to flow between two nodes. Internally, a splitter passively copies traffic for use with flow maps.



### Status LEDs

Status LEDs show the status of the module:

- The RDY LED turns GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.
- The PWR LED is illuminated when the module is receiving power from the chassis.



### PORT and TAP Numbering

Ports and TAP combinations are labeled on the module faceplate and run sequentially from left to right.

Figure 1-10: TAP-HC0-D25BC0 Module

## TAP-HC0-D35CC0 Module


The GigaTAP TAP-HC0-D35CC0 module provides 12 LX/LR TAP connections to be used as network ports running over singlemode fiber. This module has 24 ports, enabling 12 TAPs. Each port pair is arranged one above the other providing bidirectional traffic to flow between two nodes. Internally, a splitter passively copies traffic for use with flow maps.



### Status LEDs

Status LEDs show the status of the module:

- The RDY LED turns GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.
- The PWR LED is illuminated when the module is receiving power from the chassis.



### Port and TAP Numbering


Ports and TAP combinations are labeled on the module faceplate and run sequentially from left to right.

Figure 1-11: TAP-HC0-D35CC0 Module

## TAP-HC0-G100C0 Module

The GigaTAP TAP-HC0-G100C0 module provides 12 1Gb Copper TAP connections to be used as network ports. On GigaVUE-HC2 (control card version 1), the only supported speed is 1Gb. On GigaVUE-HC2 (control card version 2), 10/100Mb speed is also supported.

This module has 24 ports, enabling 12 TAPs. Each port pair is arranged with one port above the other, providing bidirectional traffic flow between two nodes. Traffic is copied through the use of a port pair, unless the port pair is in the physical bypass state. Refer to [Figure 1-12 on page 24](#).



### Status LEDs

Status LEDs show the status of the module:

- The RDY LED turns GREEN once the module has been configured in CLI, indicating it is ready to use. Until then, it is RED.
- The PWR LED is illuminated when the module is receiving power from the chassis.

### Port and TAP Numbering

Ports and TAP combinations are labeled on the module faceplate and run sequentially from left to right.

Figure 1-12: TAP-HC0-G100C0 Module

## Using the TAP-HC0-G100C0 Module for Copper Bypass

The network ports on the TAP-HC0-G100C0 module can be configured through software to be inline network ports. This allows the TAP-HC0-G100C0 module to act as a copper bypass module, providing protected inline networks for copper ports.

To use the copper bypass functionality, the GigaVUE-HC2 must be running GigaVUE-OS version 4.3 or higher. For configuration information, refer to the chapter “Configuring Inline Bypass Solution on GigaVUE TAP Modules” in the *GigaVUE-OS CLI Reference Guide*.



## Using TAP-HC0-G100C0 Module for Gigamon Resiliency for Inline Protection

Gigamon Resiliency for Inline Protection (GRIP)<sup>™</sup> is an inline bypass solution that connects two GigaVUE-HC2 nodes together so that one node provides high availability to the other node when there is a loss of power. This redundant arrangement of two GigaVUE-HC2 nodes maintains traffic monitoring by inline tools when one of the nodes is down.

GRIP<sup>™</sup> makes use of the bypass protection switch relays for protected inline networks on GigaVUE-HC2 nodes. The TAP-HC0-G100C0 module can provide physical protection for protected pairs of copper inline network ports required by the GRIP solution.

To configure the GRIP solution, the GigaVUE-HC2 must be running GigaVUE-OS version 4.4 or higher. For solution and configuration information, refer to the chapter “Configuring Inline Bypass Solutions” in the *GigaVUE-OS CLI Reference Guide*.

## Bypass Combo Modules

Security tools such as firewall and intrusion detection/protection systems are often connected inline on production networks, with traffic flowing from the network segment through the tool and then back onto the production network.

The GigaVUE-HC2 offers physical and logical inline bypass. Physical bypass provides automatic failover protection in the case of a power failure. The bypass combo modules provide the physical bypass function. As it applies to a single pair of inline network ports, the physical bypass function is as follows:

- When the module is not powered, (either the entire node is powered down or the module is removed from the node), the inline network port pair is in the physical bypass mode. That means that traffic is exchanged directly between network Port A and network Port B of the inline network pair.
- When the module is powered, the mode (inline or bypass) of the inline network port pair is controlled through software. In the physical bypass mode, the inline network port pair behaves exactly as if the module was not powered. In the inline mode, the inline network port pair behaves as any other inline network port pair configured for working with an inline tool.

The GigaVUE-HC2 supports the following 10Gb and 40Gb bypass combo modules:

- [10Gb Bypass Combo Modules on page 26](#)
- [40Gb Bypass Combo Module on page 30](#)

### 10Gb Bypass Combo Modules

There are three 10Gb bypass combo modules as follows:

- Bypass Combo Module with four SX/SR (50/125µm multimode) inline network port pairs and sixteen regular SFP+ port cages (BPS-HC0-D25A4G) ([Figure 1-13 on page 27](#))
- Bypass Combo Module with four SX/SR (62.5/125µm multimode) inline network port pairs and sixteen regular SFP+ port cages (BPS-HC0-D25B4G) ([Figure 1-14 on page 27](#))
- Bypass Combo Module with four LX/LR (singlemode) inline network port pairs and sixteen regular SFP+ port cages (BPS-HC0-D35C4G) ([Figure 1-15 on page 28](#))

Before installing any of the 10Gb bypass combo modules, the GigaVUE-HC2 must be running software version 4.1 or higher.


For internal transceiver and loss summary specifications, refer to [Bypass Combo Module Specifications on page 91](#).

## Features of 10Gb Bypass Combo Modules

The 10Gb bypass combo modules have the following features:

- Four inline network port pairs that pass traffic bi-directionally.
- Port pairs that offer optical protection switch for physical bypass.
- Sixteen regular SFP ports that can operate at 1Gb, SFP+, and SFP+ Copper ports that can operate at 10Gb. These ports can be configured as any port type.
- A mode to select either bypass or inline.
- A module that is hot swappable. Refer to procedures in [Module Removal and Replacement Procedure \(Hot Removal\)](#) on page 53.

### GigaBPS Bypass Combo Module in GigaVUE-HC2



### BPS-HC0-D25A4G




Figure 1-13: Bypass Combo Module BPS-HC0-D25A4G

### BPS-HC0-D25B4G




Figure 1-14: Bypass Combo Module BPS-HC0-D25B4G

## BPS-HC0-D35C4G




Figure 1-15: Bypass Combo Module BPS-HC0-D35C4G

### Module Status LEDs

The following module status LEDs are located on the front of the bypass combo modules:

- Rdy is the Ready LED. It has the following states:
  - RED indicates system booting or module down
  - GREEN indicates normal condition
- Pwr is the Power LED. It has the following state:
  - GREEN indicates the module is receiving power

### Port Status LEDs

The port status LEDs have the following states:

- Off indicates that the port is disabled or the link is down
- GREEN indicates that the link is established

### Ports

You can configure any two of the sixteen ports as an inline tool port pair and connect an inline tool to them.

For tool ports, you can also use ports on any module in the chassis, including ports on other bypass combo modules or ports on other GigaVUE-HC2 modules.

Ports have the following labels: X1 to X16. In the CLI, these ports are referred to as: x1 to x16.

## Inline Network Ports

Connect inline networks to the inline network ports. The inline network ports have built-in protection for power down.

The inline network ports have the following labels:

- A—Inline network port A (for network 1 through network 4)
- B—Inline network port B (for network 1 through network 4)

**NOTE:** In the CLI, these ports are referred to as: x17 to x24.

The inline network ports on BPS-HC0-D25A4G and BPS-HC0-D25B4G are colored yellow to indicate short range. The inline network ports on BPS-HC0-D35C4G are colored blue to indicate long range.

The inline network port status LEDs have the following states:

- Off indicates that the port is disabled or the link is down
- GREEN indicates that the link is established

## Mode

Mode (M) has the following labels:

- Off—Bypass
- On—Inline

The Mode LED has the following states:

- RED indicates that physical bypass is disabled
- Off indicates that physical bypass is enabled

## Using Bypass Combo Modules for Gigamon Resiliency for Inline Protection

Gigamon Resiliency for Inline Protection (GRIP)<sup>™</sup> is an inline bypass solution that connects two GigaVUE-HC2 nodes together so that one node provides high availability to the other node when there is a loss of power. This redundant arrangement of two GigaVUE-HC2 nodes maintains traffic monitoring by inline tools when one of the nodes is down.

GRIP<sup>™</sup> makes use of the bypass protection switch relays for protected inline networks on GigaVUE-HC2 nodes. The bypass combo modules can provide physical protection for protected pairs of optical inline network ports required by the GRIP solution.

To configure the GRIP solution, the GigaVUE-HC2 must be running GigaVUE-OS version 4.4 or higher. For solution and configuration information, refer to the chapter “Configuring Inline Bypass Solutions” in the *GigaVUE-OS CLI Reference Guide*.

## 40Gb Bypass Combo Module

There is one 40Gb Bypass Combo Module as follows:

- Bypass Combo Module with two SR4 (50/125µm multimode) inline network port pairs and eight regular SFP+ port cages (BPS-HC0-Q25A28). Refer to [Figure 1-16 on page 30](#).

Before installing the bypass combo module, the GigaVUE-HC2 must be running software version 5.0 or higher.

For internal transceiver and loss summary specifications, refer to [Bypass Combo Module Specifications on page 91](#).

**NOTE:** The BPS-HC0-Q25A28 can only be used on a GigaVUE-HC2 node equipped with GigaVUE-HC2 Control Card version 2 (HC2 CCv2).

### Features of the 40Gb Bypass Combo Module

The 40Gb Bypass Combo Module has the following features:

- Two 40Gb inline network port pairs that pass traffic bi-directionally.
- Port pairs that offer optical protection switch for physical bypass.
- Eight regular SFP+ ports that can operate at 1Gb or 10Gb and that can be configured as any port type.
- A mode to select either bypass or inline.
- A module that is hot swappable. Refer to procedures in [Module Removal and Replacement Procedure \(Hot Removal\) on page 53](#).

### BPS-HC0-Q25A28




Figure 1-16: Bypass Combo Module BPS-HC0-Q25A28

## Module Status LEDs

The following module status LEDs are located on the front of the bypass combo module:

- Rdy is the Ready LED. It has the following states:
  - RED indicates system booting or module down
  - GREEN indicates normal condition
- Pwr is the Power LED. It has the following state:
  - GREEN indicates the module is receiving power

## Port Status LEDs

The port status LEDs have the following states:

- Off indicates that the port is disabled or the link is down
- GREEN indicates that the link is established

## Ports

You can configure any two of the eight 10Gb ports as an inline tool port pair and connect an inline tool to them.

For tool ports, you can also use ports on any module in the chassis, including ports on other bypass combo modules or ports on other GigaVUE-HC2 modules.

Ports have the following labels: X1 to X8. In the CLI, these ports are referred to as: x1 to x8.

## Inline Network Ports

Connect inline networks to the inline network ports. The inline network ports have built-in protection for power down.

The inline network port status LEDs have the following labels:

- A—Inline network LED A (for network 1 through network 2)
- B—Inline network LED B (for network 1 through network 2)
- M—Inline network Mode LED (on is inline and off is bypass)

The inline network port status LEDs have the following states:

- Off indicates that the port is disabled or the link is down
- GREEN indicates that the link is established

**NOTE:** In the CLI, the inline network ports are referred to as q1 to q4.

## Using Bypass Combo Modules for Gigamon Resiliency for Inline Protection

Gigamon Resiliency for Inline Protection (GRIP)<sup>™</sup> is an inline bypass solution that connects two GigaVUE-HC2 nodes together so that one node provides high availability to the other node when there is a loss of power. This redundant arrangement of two GigaVUE-HC2 nodes maintains traffic monitoring by inline tools when one of the nodes is down.

GRIP<sup>™</sup> makes use of the bypass protection switch relays for protected inline networks on GigaVUE-HC2 nodes. The bypass combo modules can provide physical protection for protected pairs of optical inline network ports required by the GRIP solution.

To configure the GRIP solution, the GigaVUE-HC2 must be running GigaVUE-OS version 5.1 or higher. For solution and configuration information, refer to the chapter "Configuring Inline Bypass Solutions" in the *GigaVUE-OS CLI User's Guide*.



## GigaSMART Rear Module

GigaVUE-HC2 nodes with a GigaSMART Rear module installed can take advantage of GigaSMART's advanced processing features, including masking, slicing, tunnel decapsulation, VLAN tag insertion, de-duplication, header stripping, Adaptive Packet Filtering (APF), NetFlow generation, GTP stateful filtering, and flow sampling. You can use both H-VUE and the CLI to create GigaSMART operations combining different packet processing features, combine them with other map rule criteria, and apply them in map rules on any network port in the node.

Refer to the *GigaVUE-OS CLI User's Guide* for details on the GigaSMART features.

### GigaSMART SMT-HC0-R

The GigaSMART-HC0-R set of advanced features relies on on-board processing and backplane connections.




Figure 1-17: GigaSMART Rear Module

### Hot Swap Button LED

The hot swap (H/S) button has a BLUE LED with the following states:

- Off indicates that the module is ready to configure. When the LED is Off, the module is operating normally in the node.
- On indicates that the module is ready to be removed.

When the H/S button is pressed on an inserted module, the LED turns solid BLUE. For the hot swap procedure, refer to [Removing the Rear GigaSMART Module on page 48](#).

## GigaSMART Front Module


The GigaSMART Front module is a front-facing GigaVUE-HC2 module blending GigaSMART intelligence and port capabilities into a single module. GigaSMART licenses enable a variety of capabilities from packet de-duplication to NetFlow generation.

GigaVUE-HC2 nodes with a GigaSMART Front module installed can take advantage of GigaSMART's advanced processing features, including masking, slicing, tunnel decapsulation, VLAN tag insertion, de-duplication, header stripping, Adaptive Packet Filtering (APF), NetFlow generation, GTP stateful filtering, and flow sampling. Refer to the *GigaVUE-OS CLI User's Guide* for details on the GigaSMART features. The GigaSMART Front module also has sixteen 10Gb SFP+ and SFP+ Copper ports.

The GigaSMART Front module can be used standalone, or combined with other GigaSMART modules located in either the front or rear of the node. Since each GigaSMART module has its own compute engine, additional modules may be added as more compute power is required. The processing is not limited to the ports on the module. GigaSMART functionality is available to all ports within a clustered environment.

Before installing the GigaSMART Front module, the GigaVUE-HC2 must be running software version 4.1 or higher.

### GigaSMART Front Module in GigaVUE-HC2



### GigaSMART SMT-HC0-X16




Figure 1-18: GigaSMART Front Module

## Module Status LEDs

The following module status LEDs are located on the front of the GigaSMART Front module:

- Rdy is the Ready LED. It has the following states:
  - RED indicates system booting or alarm condition
  - GREEN indicates normal condition
- Pwr is the Power LED. It has the following state:
  - GREEN indicates the module is receiving power

## Port Status LEDs

The port status LEDs have the following states:

- Off indicates that the port is disabled or the link is down
- GREEN indicates that the link is established

## Hot Swap Button

Use the hot swap (H/S) button to put the GigaSMART Front module in a shutdown state.

The H/S button has a BLUE LED with the following states:

- Off indicates that the module is ready to configure. When the LED is Off, the module is operating normally in the node.
- Blinking indicates that the H/S button has been pressed.
- On (solid BLUE) indicates that the module is ready to be removed.

To remove a GigaSMART Front module, refer to the procedure [Removing the Front GigaSMART Module on page 49](#).



# GigaVUE-HC2 Installation Roadmap

---

This chapter provides a flow chart of the major steps you need to perform to get a GigaVUE-HC2 node unpacked, rack-mounted, installed, and connected. It also describes what you should do once you have completed the initial setup of the node. Refer to the following sections for details:

- [First Steps – Getting Unpacked, Racked, Installed and Connected on page 37](#)
- [Next Steps on page 38](#)

---

## First Steps – Getting Unpacked, Racked, Installed and Connected

You have received your GigaVUE-HC2 node and now you are ready to get up and running. [Figure 2-1 on page 38](#) shows the major steps you need to perform to get the GigaVUE-HC2 chassis out of the box, into a rack, installed with modules, plugged in, and running on your network.




Figure 2-1: Getting Started Roadmap

## Next Steps

Once you have performed the initial configuration of the GigaVUE-HC2 node, installing, connecting, and configuring the node, you are ready to get started mapping traffic between network and tool ports.

Refer to the *GigaVUE-OS CLI Reference Guide*, *GigaVUE-OS H-VUE Administration Guide*, and online help for information.

# Assembling the GigaVUE-HC2 Node

---

This chapter explains how to unpack, rack-mount, and assemble the GigaVUE-HC2 node using the components that came with your shipment.

Separate sections are provided for unpacking and rack-mounting the GigaVUE-HC2 nodes. However, the instructions for installing control cards and modules are mostly identical and are covered in single sections. Refer to the following sections for details:

- [Unpacking the GigaVUE-HC2 Shipment on page 39](#)
- [Rack-Mounting the GigaVUE-HC2 Chassis on page 40](#)
- [Installing Power Modules in the GigaVUE-HC2 Chassis on page 43](#)
- [Installing Control Card in the GigaVUE-HC2 Chassis on page 46](#)
- [Installing the Rear GigaSMART Module on page 48](#)
- [Removing the Rear GigaSMART Module on page 48](#)
- [Removing the Front GigaSMART Module on page 49](#)
- [Installing and Removing Modules Procedure on page 51](#)
- [Module Removal and Replacement Procedure \(Hot Removal\) on page 53](#)

---

## Unpacking the GigaVUE-HC2 Shipment

The GigaVUE-HC2 node is shipped partially assembled. The chassis and parts kit are shipped in one box – control card and modules are shipped in their own separate boxes. Use the following procedure to unpack the node:

1. Inspect the shipping boxes. If any of the cartons were damaged, file a claim with the carrier who delivered them.
2. Open the box containing the GigaVUE-HC2 chassis and remove the parts kit from the top of the shipment. The parts kit contains the power cords, console cable and adapter, optional cable management assembly, and power supply covers.

If you plan on installing the optional cable management assembly, set both the assembly and its matching custom rack ear aside for installation.

3. Open the following additional boxes and set them aside for assembly (each control card and module is shipped in separate boxes):
  - control card (one per chassis)
  - modules
4. Leave all protective filler panels in place in the chassis. **DO NOT** install the control card or modules yet. Gigamon recommends rack-mounting the GigaVUE-HC2 chassis empty because of its weight (~37lb).




Figure 3-1: GigaVUE-HC2

## Rack-Mounting the GigaVUE-HC2 Chassis

This section describes how to rack-mount the GigaVUE-HC2 chassis in a standard 2RU rack space using the hardware provided with the chassis. You can install the GigaVUE-HC2 chassis in two-post or four-post racks with a minimum depth of 16in.

### Safety Precautions

Before you get started rack-mounting the GigaVUE-HC2 chassis, make sure you have read the following safety precautions:

- There are a wide variety of racks available on the market. Make sure you consult the instructions provided by your rack vendor for detailed mounting instructions before installing the GigaVUE-HC2 chassis.
- Make sure you install any stabilizers provided for the rack before installing the chassis. Unsecured racks can tip over and cause injury or death.
- Make sure you install devices in the rack from the bottom up with the heaviest devices at the bottom.
- Make sure you provide adequate ventilation to the nodes installed in the rack.



## Rack-Mounting Procedure

Use the following procedure to rack-mount the GigaVUE-HC2 chassis and install the optional cable management assembly:

1. **Decide whether you want to front-mount or center-mount the chassis in the rack.** Front-mounted nodes will sit flush with the front of the rack while center-mounted nodes will extend in front of it.

The GigaVUE-HC2 chassis is shipped with its standard rack ears attached facing forward in the front-mount position. You can reverse the direction of the rack-ears to center-mount the node.

**IMPORTANT:** The optional cable management assembly can only be used when front-mounting the GigaVUE-HC2 chassis. Refer to the next step for details.

### Front-Mount GigaVUE-HC2

#### Front-Mount Position (As Shipped)

Rack ears face towards the front of the node for front-mounting.

#### Center-Mount Position

Reverse the rack ears so they face towards the rear of the node for center-mounting.




Figure 3-2: Rack Ears for Front Mount (Reverse Rack Ears for Center Mount)

2. Make sure you have not installed any modules in the chassis yet. Gigamon recommends rack-mounting the GigaVUE-HC2 chassis before installing these items to make it easier to handle during the installation.
3. Select a suitable location for the rack that will hold the GigaVUE-HC2 chassis. Choose a location that is clean, dust free, and well-ventilated. You will need access to grounded power sources. Avoid areas where heat, electrical wire, and electromagnetic fields are generated.

Plan for enough clearance in front of a rack so you can access the modules easily (approximately 25in) and enough clearance in the back of the rack to allow sufficient airflow and installation of the rear components such as power supplies. Also, if you plan to install the optional cable management assemblies, allow another 3.5in of clearance at the front of the node.

4. Locate an open 2RU rack space and lift the node into place. It takes two people, or a scissor lift to place the GigaVUE-HC2 in the rack. Insert a screw through the rack ear on each side into the rack, to hold the node in place. Tighten the screws.
5. Carefully lift the chassis into the rack and place a screw on each side to hold the chassis.
6. Tighten the screws and add additional screws to secure the node. **Use two screws on each rack ear.**


## Four-Post Rack Mounting

To mount the GigaVUE-HC2 in a four-post rack, use rack ears and full-length brackets. The rack ears attach at the front of the unit and the brackets attach at the rear, as follows:

- Attach the rack ears so they face towards the front of the system for mounting in four-post racks.
- Attach the full-length brackets to the sides of the GigaVUE-HC2 with enough free play to position them to fit your rack's dimensions. After the brackets are attached to the rack's rear posts, tighten the bracket connections to the sides of the GigaVUE-HC2.

Refer to [Figure 3-3 on page 42](#) for retracted and extended bracket installation.

Retracted Bracket



Extended Bracket




*Figure 3-3: Retracted and Extended Bracket Installation*

## Installing Power Modules in the GigaVUE-HC2 Chassis

The GigaVUE-HC2 chassis is shipped without either of its two separate power modules installed. Use the following procedure to install them.

**NOTE:** If you are installing DC power modules, you will need to wire power to the screw terminals on the power modules before installing them in the chassis. There is not enough room to service the screw terminals once the modules are installed in the chassis. Refer to [Connecting -48V DC Power Supplies on page 59](#) for instructions on connecting DC power modules.

1. Make sure you are wearing an ESD-preventive wrist or ankle strap.
2. Locate the power modules and remove them from their packaging. Each module is shipped in its own box.



*Figure 3-4: Power Module (AC Version Shown)*

3. Carefully slide the first power module into the matching receptacles at the rear of the node ([Figure 3-4 on page 43](#)), making sure to fit the tab at the base of the module into the matching bay at the bottom of the receptacle. Push gently to seat the unit firmly in the chassis.
4. Tighten the thumb screws to lock the power module into the chassis.
5. Repeat the previous two steps for the second power module.

## Installing the Cable Management Trays in the GigaVUE-HC2 Chassis

Decide whether you want to install the optional cable management assembly.

The GigaVUE-HC2 chassis includes two cable management trays for installation at the side of the node. Installing the cable management trays is optional. However, because of the high number of ports potentially available on the GigaVUE-HC2 node, Gigamon recommends installing the cable management trays. Use the following procedure:

1. Remove the cable management trays from the foam packaging shipped on top of the GigaVUE-HC2 chassis (Figure 3-5).

Cable Management Trays as shipped.



Figure 3-5: Cable Management Trays

2. Remove the front panel from each of the cable management trays by loosening the thumb screws.
3. The cable management assembly is included in the parts kit with the chassis shipment. Installation of the cable management assembly is optional.

To install the cable management assembly on the GigaVUE-HC2 node, you must attach it to the rack ear on the left and right sides of the chassis rack ear:

- a. Locate the cable management assembly (Figure 3-6).

Cable Management Assembly attaches to rack ear for GigaVUE-HC2 node.




Figure 3-6: GigaVUE-HC2 Cable Management Assembly and Rack Ear

- b. Attach the Cable Management assembly to the forward facing rack ear tab with two machine screws.

## Rack Ear for Cable Management

### Rack Ear (As Shipped)

Rack ear tab runs the entire height of the node with forward-facing tabs.

### Rack Ear for Cable Management Assembly

Rack ear features forward-facing tabs for attachment of optional cable management assembly.





Figure 3-7: Standard Rack Ears on GigaVUE-HC2

If you installed the custom rack ear for the cable management assembly in [Step 3](#), you can now attach the assembly using the four screws provided. The screws attach through the recessed holes on the inside of the rack ear and into the cable management assembly, as shown in [Figure 3-8 on page 45](#).



### Cable Management Assembly Attached

The screws attach from the inside of the tabs. You may need to partially remove the modules in bays 1 and 4 to fully attach the cable management assembly screws.

Figure 3-8: Cable Management Assembly Attached to Node

4. As shown in [Figure 3-8](#), the thumb screws on the cable management assembly's front panel allow quick removal and reattachment whenever you want to route cables.
5. Use the provided screws to attach the lower halves of the cable management tray to the top and bottom of the GigaVUE-HC2 chassis. Each lower half has a protruding "lip" on one side of the assembly – position this lip so you can route cables into the assembly.

- Attach the top assembly with the lip at the top of the node.
- Attach the bottom assembly with the lip at the bottom of the node

**This completes the assembly of the cable management trays on the GigaVUE-HC2.**

---

## Installing Control Card in the GigaVUE-HC2 Chassis

Once the GigaVUE-HC2 chassis is successfully installed in the rack, you are ready to start building up the node. Start by installing the control card in the rear of the GigaVUE-HC2.

- [Avoid Electrostatic Damage! on page 46](#)
- [Control Card Installation Procedure on page 46](#)

**NOTE:** Refer to [Control Card Installation Procedure on page 46](#) for control card replacement procedures in a variety of different deployment scenarios.

### Avoid Electrostatic Damage!

**IMPORTANT:** Always take precautions to avoid electrostatic damage during control card and module installation:


- Always use an ESD-preventive wrist or ankle strap and ensure that it makes good skin contact. The strap can be connected to one of the following:
  - ESD wrist strap connector. The GigaVUE-HC2 chassis provides a connector at the front of the chassis for this purpose labeled **ESD GND PT.**
  - Captive installation screws on an installed module or power supply.
  - Any unpainted surface on the chassis.
- Handle cards by the edges only.
- Avoid contact between the cards and clothing. The wrist strap protects only the module from ESD voltages on the body. ESD voltages on clothing can still cause damage.

### Control Card Installation Procedure

Use this procedure for initial installation of GigaVUE-HC2 control cards, either the original control card or HC2 CCv2.

**IMPORTANT:** Because there is only one control card, hot swapping is not possible.


1. Make sure you are wearing an ESD-preventive wrist or ankle strap.
2. Remove the protective fan tray from the back of the unit. This opens the area to insert the control card.



*Figure 3-9: Back of Node Shows Opening for Control Card*

3. Locate the control card and remove it from its packaging.
4. Carefully align the tabs at the sides of the control card rack.
5. Slide the control card into the guides until it is firmly connected at the back of the card.

#### GigaVUE-HC2 Control Card Assembly



When fully inserted, close the latches on the two back corners and attach the screws into the frame.


*Figure 3-10: Installing Control Card to the rear of the GigaVUE-HC2*

**This completes the installation of the control card on the GigaVUE-HC2.**

## Installing the Rear GigaSMART Module

Use the following procedure to install the rear GigaSMART module with the power on.

For installing other GigaVUE-HC2 modules, refer to [Module Installation Procedure on page 52](#).



Bay for the rear GigaSMART

Captive screws

1. Unpack all the components of the GigaVUE-HC2, and view the rear of the chassis.
2. Remove the filler panel covering the bay below the fan assembly by removing the two captive screws.  
**NOTE:** Do not remove the filler panel if you do not plan to install a GigaSMART module in that bay.
3. Insert the GigaSMART module into the open bay and fasten by tightening the two captive screws.

The rear GigaSMART module is installed as follows.



## Removing the Rear GigaSMART Module

Use the following procedure to remove the rear GigaSMART module from the node with the power on.

For removal of other GigaVUE-HC2 modules, refer to [Module Removal and Replacement Procedure \(Hot Removal\) on page 53](#).

**IMPORTANT:** Hot removal of the GigaSMART module without following the listed steps can cause system instability and require a reboot.



Before starting, make sure you are wearing an ESD-preventive wrist or ankle strap.

1. Save map rules with the following CLI command:

**config text generate active running save <name.txt>**

Refer also to [Backing Up Running Configuration on page 49](#).

2. Press the H/S button to prepare the module for removal. Wait for the LED to turn solid blue.
3. Slide the module out of chassis and store it in a static-safe location.
4. Insert the new GigaSMART module.
5. To verify the module is operationally up, issue the following CLI command:

**(config) # show cards**

6. Apply GigaSMART licenses with the following CLI command:

**license install box id <#> key**

## Backing Up Running Configuration

Use the information in this section to back up the running configuration.

Use the following command to back up to a SCP/TFTP/HTTP server:

**(config) # configuration text generate active running upload <upload URL> <filename>**

This command uses FTP, TFTP, or SCP to upload the running configuration to a text file on remote storage. The format for the **<upload URL>** is as follows:

**[protocol]://username[:password]@hostname/path/filename**

For example, the following command uploads a text configuration file based on the active running configuration and uploads it to an FTP server at 192.168.1.49 with the name **config.txt**:

**(config) # configuration text generate active running upload ftp://myuser:mypass@192.168.1.49/ftp/config.txt**

---

## Removing the Front GigaSMART Module

Use the following procedure to remove the front GigaSMART module from the node with the power on. The procedure shuts down the GigaSMART port and the sixteen 10Gb SFP+ ports on the front GigaSMART module.

For removal of other GigaVUE-HC2 modules, refer to [Module Removal and Replacement Procedure \(Hot Removal\) on page 53](#).

**IMPORTANT:** Hot removal of the GigaSMART module without following the listed steps can cause system instability and require a reboot.

Before starting, make sure you are wearing an ESD-preventive wrist or ankle strap.

1. Save map rules with the following CLI command:

**config text generate active running save <name.txt>**

Refer also to [Backing Up Running Configuration on page 49](#).

2. To prepare the module for removal, press and hold the H/S button, then release it. The LED will blink for a few seconds.

**NOTE:** Pressing the H/S button is the same as issuing the following CLI command:

**(config) # card slot <slot ID> down**

3. Wait for the module to shut down: Rdy LED goes red; H/S LED goes solid blue.
4. Slide the module out of the chassis and store it in a static-safe location.
5. Insert the new GigaSMART module.
6. Wait for the module to come back up: Rdy LED goes green; H/S LED goes off.
7. To verify the module is operationally up, issue the following two CLI commands:

**(config) # show cards**

**(config) # show card slot <slot id>**

**NOTE:** The output of the **show cards** command displays the operational status of the GigaSMART Front module as up in the Oper Status field, as follows:

```
(config) # show cards
```

Slot	Config	Oper Status	HW Type	Product Code	Serial Num	HW Rev
cc1	yes	up	HC2-Main-Board	132-00AN	1AN0-00E4	B1-25
1	yes	<b>up</b>	SMT-HC0-X16	132-00AT	1AT0-0151	A0-5

However, the processor on the GigaSMART Front module takes a minute to become operationally up. The **show card slot <slot id>** command displays the status of the card as well as the status of the processor. Issue the **show card slot <slot id>** command to verify the processor state in the e1 State field. You may have to issue the command a few times to watch the e1 State transition from down to up, as follows:

```
(config) # show card slot 1/1
```

Slot	Config	Oper Status	HW Type	e1 State	e2 State
1	yes	up	SMT-HC0-X16	<b>down</b>	N/A

```
(config) # show card slot 1/1
```

Slot	Config	Oper Status	HW Type	e1 State	e2 State
1	yes	up	SMT-HC0-X16	<b>up</b>	N/A

8. Apply GigaSMART licenses with the following CLI command:

**license install box id <#> key**

---

## Installing and Removing Modules Procedure

The procedure for installing modules is to remove the filler panels, and install the module. Then fasten with the blue ejector lever and tighten the thumb screw on top of the lever. The following procedure has the details.

### Hot Swapping Modules

Modules are hot-swappable – they can be installed or removed from the chassis with the power on. **To remove a module safely with the power on, you must follow the procedure in *Module Removal and Replacement Procedure (Hot Removal)* on page 53.**

**Install proper software versions prior to inserting any new modules.**

Gigamon often makes new modules available for GigaVUE-HC2 nodes. New modules are usually introduced starting with a new software release. Make sure you install the supporting software release before physically installing the new module.

If you do install a new module before its supporting release, the module will appear in **show cards** output with an **Operational Status** of **unsupported**.

In some cases, if you subsequently upgrade the node to the release that does support the new module, it can appear persistently in the **show cards** output with an **Operational Status** of **inserted**. To make the module operational, you must unconfigure it with the **no card slot x** command, followed by configuring the module with **card slot x**.



## Module Installation Procedure

Use the following procedure, for GigaVUE-HC2 modules, except the GigaSMART Rear module, which is described in [Installing the Rear GigaSMART Module on page 48](#).

1. Make sure you are wearing an ESD-preventive wrist or ankle strap.
2. Locate the modules and remove them from their packaging.
3. Remove the protective filler panels from the target bays for all modules to be installed. Keep the filler panels so they can be easily reused if the module is ever removed. You can install modules in any of the four available front bays on the GigaVUE-HC2 – the order is not important.

**NOTE:** To prevent any improper air flow and overheating the node, **do not leave any bays uncovered**.

4. Pull out the dark blue lever on the left top of the module. Carefully slide the module into the bay. Push the lever back in and tighten using the thumb screw on the lever..



**NOTE:** Modules can be installed in any available front bays on the GigaVUE-HC2 – the order is not important. However, keep the filler panels inserted on any unused bays to ensure proper airflow and ventilation.

*Figure 3-11: Installing Modules*

5. Install any additional modules by repeating the previous two steps.

**NOTE:** The first time you install a module in the node, you need to configure the node to recognize it with the **card** command and save your changes with **write memory**. Refer to [Configure Modules and Enable Ports on page 67](#) for details.

**This completes the installation of the modules on the front of the GigaVUE-HC2.**

---

## Module Removal and Replacement Procedure (Hot Removal)

Modules can be removed from the node with the power on.

Use the following procedure for GigaVUE-HC2 modules, except the GigaSMART modules described in [Removing the Rear GigaSMART Module on page 48](#) and [Removing the Front GigaSMART Module on page 49](#).

**NOTE:** Some larger transceivers (such as copper SFP+), when inserted into ports X1 and X3 on modules PRT-HC0-X24, BPS-HC0-D25A4G, BPS-HC0-D25B4G, and BPS-HC0-D35C4G, may physically interfere with opening or closing the module latch. When possible, use these transceivers in ports other than X1 and X3. Otherwise, the transceiver and cabling for those ports will first need to be removed prior to engaging the latch.

**IMPORTANT:** Hot removal of modules without following the listed steps can cause system instability and require a reboot.

Before starting, make sure you are wearing an ESD-preventive wrist or ankle strap.

### Replacing a Module with the Same Type of Module

1. Shut down the module to prepare for removal with the following CLI command:  
**(config) # card slot <slot id> down**
2. Slide the module out of the chassis and store it in a static-safe location.
3. Insert the new module of the same type.

### Replacing a Module with a Different Type of Module

1. Remove all packet distribution configuration related to the module to be removed.
2. Shut down the module to prepare for removal with the following CLI command:  
**(config) # no card slot <slot id>**
3. Slide the module out of chassis and store it in a static-safe location.
4. Insert the new module of the different type.
5. Issue the following CLI command to make the card available for configuration:  
**(config) # card slot <slot id>**

---

## Next Steps

Refer to [Configuring Basic GigaVUE H Series Settings on page 62](#) for information on getting connected with the GigaVUE-OS to make your initial configuration settings.



# Basic GigaVUE H Series Connections and Configuration

---

This chapter describes how to establish your first configuration session with the GigaVUE-HC2 and set the basic initial configuration options necessary to get the node up and running.

Refer to the following sections for details:

- *Grounding the GigaVUE-HC2 Chassis* on page 56
- *Connecting Power to the GigaVUE-HC2* on page 57
- *Fan Trays* on page 60
- *Connecting Serial Console and Mgmt Ports* on page 62
  - *Connecting -48V DC Power Supplies* on page 59
- *Configuring Basic GigaVUE H Series Settings* on page 62
  - *Access the Command-Line Interface over the Console Port* on page 62
  - *Run the Jump-Start Script* on page 64
  - *Configure Modules and Enable Ports* on page 67
- *Command-Line Basics* on page 69
  - *Command-Line Modes* on page 69
  - *Entering Commands in the CLI* on page 71
  - *Command-Line Syntax – Entering Commands* on page 72
- *The Basic Commands* on page 74
- *Completing the Initial GigaVUE H Series Setup* on page 77

## Grounding the GigaVUE-HC2 Chassis



The GigaVUE-HC2 chassis is drilled for ground screws near the bottom left corner at the rear of the chassis. Connect grounding wire with spade lugs to the ground screws on the chassis and earth ground using the following procedure.

1. Locate the grounding points near the bottom left corner at the rear of the chassis to the right of the power plug. There are two pairs of grounding points as shown in [Figure 4-1 on page 56](#).
2. Install ground screws meeting the following specifications:  
**#8 Panhead, Phillips-drive, Exterior SEM screw.**  
**Thread size = 32**  
**Length = 1/2in (1.27cm)**



*Figure 4-1: Grounding Points for Ground Screws (GigaVUE-HC2 Shown)*

3. Connect grounding wire with spade lugs both to the ground screws and to earth ground. The specifications for the ground wire and lugs are as follows:  
**Standard Wire 12-16 (AWG); Stud Size #6 (0.138in/0.351cm); Spade Width 0.32in/0.813cm**
4. Tighten the screws to secure both the chassis ground screws and the earth ground screws.



## Connecting Power to the GigaVUE-HC2


The procedure for connecting power to the GigaVUE-HC2 is similar to the other GigaVUE H Series nodes:

GigaVUE Chassis Type	Number of Power Modules	Power Supplies per Modules
GigaVUE-HC2	2	1

In all cases only a single power module is required to operate the node. However, connecting both modules provides redundant power.

1. Plug an approved C13 power cable into each of the power modules at the rear of the GigaVUE-HC2 chassis.

**NOTE:** For information on connecting the optional DC power modules, refer to [Figure 4-4 on page 59](#).



Power module -  
Three-prong power  
supply

*Figure 4-2: Connecting AC Power (GigaVUE-HC2)*

2. Plug the other end of the power cables into a power source that can supply adequate power. For optimal power protection, plug the power modules into separate circuits.

When connecting to the external AC power source, ensure that a Surge Protective Device (SPD) is installed at the AC power inlet.

For information on GigaVUE-HC2 power requirements, refer to [AC- and DC-Powered GigaVUE-HC2 on page 11](#).


3. Power is turned on when the unit is plugged in, and turned off when the unit is unplugged.

Refer to [Connecting Serial Console and Mgmt Ports on page 62](#) for information on how to connect to the GigaVUE-OS command-line interface.

To remove a power module, refer to [Removing a Power Module on page 58](#).

## Removing a Power Module

When removing a power module, refer to the following label on the chassis:



*Figure 4-3: Power Caution Label*

To remove a power module:

1. Power down the module by disconnecting the power inputs.
2. Wait about 90 seconds for the node to stabilize.
3. Remove the power module.

**NOTE:** Do not remove a power module while inputs are still connected.

## Connecting -48V DC Power Supplies

The GigaVUE-HC2 is available with DC power supplies. This section provides instructions for connecting a -48V DC power source to the DC power supplies.

### To connect a -48V DC input to the screw terminal DC power supply:

1. Remove the safety cover from the power terminals.
2. Connect the power supply ground terminal ( $\frac{-}{\perp}$ ) to earth ground.




Figure 4-4: DC Power Module

3. Connect the positive and negative power cables to the screw terminals using a Phillips screwdriver.
  - The top connector on the DC power supply is the **0V** connector.
  - The bottom connector on the DC power supply is the **-48V** connector.
4. Replace the safety cover over the power terminals.
5. Connect the neutral and negative power cables to the DC power source as follows:
  - Connect the neutral wire to the 0V (RTN) connector on the DC power source.
  - Connect the negative wire to the -48V connector on the DC power source.

**IMPORTANT:** As shown in [Figure 4-4](#), the leads to the DC power supplies on the GigaVUE-HC2 node should attach from the side of the chassis **away** from the terminal block. Run the wires to avoid obstructing airflow for the adjacent fans.

6. Repeat [Step 2](#) through [Step 5](#) for the other power supply in the GigaVUE-HC2 chassis:
  - **GigaVUE-HC2** – Two DC power supplies

## Fan Trays

Fan trays are field-replaceable and hot swappable. If a fan tray fails, you replace the fan tray without powering down the GigaVUE-HC2. Refer to the following sections for details:

- [Checking Fan Status on page 60](#)
- [Configuring SNMP Notification on page 60](#)
- [Replacing a Fan Tray on page 60](#)

### Checking Fan Status

A Fan LED is located on the front of the GigaVUE-HC2 chassis and provides fan status. The LED is green when the fans are operating and red when they are not. Refer to [Figure 4-5 on page 60](#) for the location of the Fan LED.




Figure 4-5: Fan LED Location on GigaVUE-HC2 Front

### Configuring SNMP Notification

Use the following CLI command to configure a notification that will be sent when the fan status changes:

```
(config) # snmp-server notify event fanchange
```


### Replacing a Fan Tray

Replace a failed fan tray with a working fan tray using the following procedures.

**NOTE:** Work quickly to remove the failed fan tray and insert the working fan tray. The GigaVUE-HC2 should not be without cooling for more than 60 seconds.

To remove a fan tray:

1. Locate the two screws on either side of the fan tray as shown in [Figure 4-6 on page 61](#).



*Figure 4-6: Fan Tray Screw Location on GigaVUE-HC2 Rear*

2. Use a Phillips screw driver to remove the two screws.
3. Pull the failed fan tray out of the slot and set it aside.

To insert a fan tray:

1. Place the working fan tray into the empty slot and slide it in until it is flush with the chassis rear and will not slide in any further.
2. Use a Phillips screw driver to tighten the two screws.

---

## Connecting Serial Console and Mgmt Ports

### To make basic GigaVUE-HC2 connections (serial console and Mgmt ports):

1. Locate the DB9-to-RJ45 serial cable provided with the GigaVUE-HC2. This cable is called a *console cable*.  
**NOTE:** This cable is Cisco-compatible. Refer to [Appendix D, Console Port Signaling and Cabling](#) for pinout details.
2. Connect the RJ45 end of the console cable to the **console** port on the left.
3. Connect the DB9 end of the console cable to a PC's COM port.
4. Connect a standard Ethernet cable (Cat5e or better) to the 10/100/1000 **Mgmt** port on the chassis.
5. Connect the other end of the Ethernet cable to an Ethernet network.

---

## Configuring Basic GigaVUE H Series Settings

This section describes how to perform the initial configuration of basic GigaVUE H Series node settings over a serial terminal connection to the console port.

The system administrator must initially log in with a default **admin** account using a default password, and then must immediately change the password through the **jump-start** script. Refer to [Access the Command-Line Interface over the Console Port on page 62](#).

Once you have used the console port to configure the Mgmt port's network properties, you can configure the GigaVUE H Series node remotely using the Mgmt port's network connection.

The same commands are available in the GigaVUE-OS command-line interface regardless of whether you are connected over the Mgmt or console port.

## Access the Command-Line Interface over the Console Port

Access to the control card is through the console port on the left side on the front of the GigaVUE-HC2.


1. Make the basic power and console cable connections described in [Connecting Serial Console and Mgmt Ports on page 62](#) and power on GigaVUE-HC2.
2. Start a terminal application on the PC. Common terminal applications include TeraTerm, PuTTY, and Hyperterminal.
3. Select the COM port connected to the console cable attached to control module. For example, **COM1**.
4. Configure the port settings for the console connection as follows:
  - **Bits per second** – 115,200
  - **Data bits** – 8
  - **Parity** – None

- **Stop bits** – 1
- **Flow control** – None

**NOTE:** You can change the console port's speed if you need to by using the procedure in [Changing the Console Port's Speed on page 64](#).

**NOTE:** If you experience problems connecting to a Cisco Terminal Server, try changing the console port's speed to 9600 bps using the procedure in [Changing the Console Port's Speed on page 64](#) and reconnecting.

[Figure 4-7 on page 63](#) shows an example of how these settings are configured in Hyperterminal.



*Figure 4-7: Setting COM Port Properties for the Console Connection*

5. Start the terminal connection. You may need to press **Enter** a few times before you see the **login:** prompt.
6. Log in to the command-line interface with the following default user account and password:

<b>User</b>	<b>admin</b>
<b>Password</b>	<b>admin123A!</b>

Starting in software version 4.7, the **configuration jump-start** automatically starts and forces a password change.

The system administrator must change the password on the default **admin** account through the **jump-start** script. The default password (admin123A!) is no longer allowed. Refer to [Run the Jump-Start Script on page 64](#) for details.

A password must meet the following standards:

- include 8-30 characters
- include at least one numeral
- include at least one upper case letter
- include at least one lower case letter

- include at least one special character (for example, !, @, #, \$, %, ^, &, or \* – ASCII 0x21, 0x2F, 0x3A, 0x40, 0x5B, 0x5F, 0x7B, 0x7E)

At the Admin password? prompt in the **jump-start** script, enter a new password that meets the standards, then confirm the password.

You will also configure some Admin and Monitor level users with the procedure described in [Initial User Account Configuration on page 82](#).

## Changing the Console Port's Speed

You can change the console port's speed using the following procedure:

1. Establish a serial console connection to the console port.
2. Reboot the node with the **reload** command.
3. Watch for the **Press Enter to boot this image, or any other key for boot menu** message. When it appears, press any key **except** Enter to access the Boot Menu.
4. When the Boot Menu appears, press the **C** key to enter command prompt mode.
5. Use the following command to change the baud rate:
 

```
=>setenv baudrate <baudrate>
```
6. Save your changes with the following command:
 

```
=>saveenv
```
7. Reboot the node with the following command:
 

```
=>boot
```
8. Remember to set the baud rate for your terminal server to the same **<baudrate>** you specified in this procedure.

## Run the Jump-Start Script

Gigamon provides GigaVUE H Series nodes with a **jump-start** script that walks you through the process of configuring basic settings. Run this script as follows:

1. Switch to **Configure** mode.

The GigaVUE H Series provides three command entry modes, each with increasingly powerful rights – **Standard**, **Enable**, and **Configure**. The jump-start script is only available in Configure mode:

- a. Type **en <Enter>** to switch to Enable mode.

The system prompt changes from **[hostname] >** to **[hostname] #**.

- b. Type **config t <Enter>** to switch to Configure mode.

The system prompt changes from **[hostname] #** to **[hostname] (config) #**.

2. Run the jump-start script with the following command:

```
(config) # config jump-start
```

3. Follow the jump-start script's prompts to configure each of the settings listed in the following table.



**NOTE:** If you change your mind about a particular setting, you will have a chance to change it at the end of the script.

<b>Hostname</b>	The hostname appears in the system prompt and is used to identify the chassis in SNMP traps.
<b>Management Port Network Settings</b>	<p>Use either DHCP or specify a static IP address and netmask. If you do not use DHCP, you are prompted to configure the following additional options:</p> <ul style="list-style-type: none"> <li>• <b>Default Gateway</b> Supply the IP address of the default gateway for the node.</li> <li>• <b>DNS Server</b> Supply the IP address of the DNS server for the node. A valid DNS server is required for successful use of both Telnet and TACACS+.</li> <li>• <b>Domain Name</b> Supply the domain name for the node (for example, mycompany.com).</li> </ul>
<b>Enable IPv6?</b>	You can enable the use of IPv6 for the management port. IPv6 is used in addition to IPv4 if you enable this option. If you enable the IPv6 you have the option of enabling IPv6 auto-configuration or specifying a static address.
<b>Security Settings</b>	<p>Enable the following security settings:</p> <ul style="list-style-type: none"> <li>• <b>secure cryptography mode</b></li> <li>• <b>secure passwords mode</b></li> <li>• <b>minimum password length</b></li> </ul> <p>Refer to the <i>GigaVUE-OS CLI Reference Guide</i> for information on security.</p>
<b>Admin Password</b>	The password for the <b>admin</b> account must be changed to a non-default password.
<b>Cluster Enable?</b>	<p>Enable cluster support if this node will be a part of a cluster of connected GigaVUE nodes. If you enable cluster support, the jump-start script prompts you to supply the <b>Cluster ID</b>, <b>Cluster Name</b>, and <b>Cluster Mgmt Virtual IP Address</b>. You can join an existing cluster by supplying values that match existing settings.</p> <p><b>NOTE:</b> For clustered nodes configured to use the eth1 port on a control card as both the Mgmt and Cluster Management port, keep in mind that NTP is also used over the eth0 Mgmt port on the GigaVUE H Series node. In a case like this, you can only use one or the other.</p> <p>If clustering is enabled, you will not be prompted for a box ID in the next step.</p> <p>Refer to the <i>GigaVUE-OS CLI Reference Guide</i> for information on setting up a cluster.</p>
<b>Box ID for the Node</b>	<p>Supply a numerical box ID for the node. This box ID is used to identify network/tool ports in the node – the format is box ID/ slot ID/port ID.</p> <p>You will be prompted for a box ID only if clustering was not enabled in the previous step.</p>

4. Review your settings. You can change a setting by specifying its listed line number and re-entering the setting.
5. When you are satisfied with your settings, exit the script as prompted. GigaVUE automatically saves your settings.
6. Restart the node with the **reload** command.

## Need to Change Any Settings?

If you need to change any of the settings you made in the jump-start script, you can either run the script again or change individual settings using the following commands in the Configure command mode:

- Use the **hostname** command to change the node's hostname.
- Use the **interface eth0** command to reconfigure or fine-tune Mgmt port settings, including basic IP settings (DHCP or static address and subnet mask) and physical parameters (duplex, MTU, and speed).
- Use the **ip** command to change the default gateway, DNS server, and domain name.
- You can also use the **username admin password <password>** command to change the **admin** user's password. Refer to [Changing the admin Account Password on page 82](#).

Refer to [The Basic Commands on page 49](#) for a quick summary of the available GigaVUE H Series commands.

## Configure Modules and Enable Ports

Modules must be configured and ports enabled before they can be used on the GigaVUE-HC2. Use the following procedure to bring up all modules and enable ports before starting to issue commands in the CLI:

1. Connect to console port as described in the previous section.
2. Wait at least two minutes after the system prompt appears for the modules to be initialized and then switch to **Configure** mode.

The GigaVUE H Series provides three command entry modes, each with increasingly powerful rights – **Standard**, **Enable**, and **Configure**. The jump-start script is only available in Configure mode:


- a. Type **en** <Enter> to switch to Enable mode.  
The system prompt changes from *[hostname]* > to *[hostname]* #.
  - b. Type **config t** <Enter> to switch to Configure mode.  
The system prompt changes from *[hostname]* # to *[hostname]* (config) #.
3. Reset the terminal settings to match the current window with the following command:  
(Config) # terminal resize
  4. Use the following command to check module status:  
(Config) # show cards
  5. Verify the following in the **show cards** output:
    - **Box ID** is not empty.
    - **Config** shows **yes** for all cards.
    - **Oper Status** shows **up** (or **inserted**) for all modules.
  6. If **Config** does not show **yes** for all modules after two minutes, take the action corresponding to your **show cards** output, as follows:

show cards Output:	Corrective Action
<b>Config</b> does not show <b>yes</b> for any modules (including control cards)	(config) # chassis box-id <integer> (config) # card all
<b>Config</b> shows <b>yes</b> for control cards but not one or more modules	(config) # card all

The **card all** command configures the node for all currently unconfigured modules. However, it can only be used after the node's box ID has been configured as reported at the top of the **show cards** output in [Figure 4-8 on page 68](#).

7. Use the **show cards** command again to verify the following:
  - **Box ID** is not empty.
  - **Config** shows **yes** for all modules.
  - **Oper Status** shows **up** (or **inserted**) for all modules.

Figure 4-8 on page 68 illustrates the **show cards** output for a GigaVUE-HC2 with properly configured modules.



```
hc2-0043 (config) # show cards box-id 1

Box ID: 1
Slot Config Oper Status HW Type Product Code Serial Num HW Rev
-----
cc1 yes up HC2-Main-Board 132-00AN 1AN0-0043 3.2-24
1 yes up HC2-GigaTAP-Tx 132-00B3 1B30-0003 1.1-47
3 yes up HC2-X24 132-00BD EEEE-FFFF A0-a2
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
hc2-0043 (config) #
```

*Figure 4-8: Successful show cards Output*

8. Issue a **show port** command to determine the port numbers that need to be enabled.
9. Use the **port** command with the **admin** argument to enable ports on modules. For example, the following command enables all ports on a PRT-HC0-X24 module:  
`(config) # port 1/1/x1..x24 params admin enable`
10. Save your changes so that the cards and ports come up automatically at the next reboot:  
`(config) # write memory`

---

## Command-Line Basics

This section provides a quick orientation to the GigaVUE-OS command-line interface – how to enter commands, how to get help, and so on.

### Command-Line Modes

The GigaVUE-OS can operate in one of three modes, each with its own set of available commands – Standard, Enable, and Configure. When you first launch the CLI, you start in Standard mode with access to a limited amount of commands used to review node status. As you move from **Standard** mode to **Enable** mode to **Configure** mode, both the power and the number of commands available increase, as summarized in [Figure 4-9 on page 70](#).

#### Differences in Commands for admin and default Level Users

The commands available in the GigaVUE-OS are also different depending on whether you are logged in as **admin** or **default** level user. Commands listed in bold in [Figure 4-9 on page 70](#) are only available to **admin** level users.



Figure 4-9: GigaVUE-OS Command-Line Modes

**NOTE:** If you are working simultaneously with multiple GigaVUE nodes, you may want to assign each a separate hostname so its easy to identify separate terminal sessions from the system prompt. Admin users can do this in **Configure** mode with the **hostname <name>** command; refer to [Configuring the GigaVUE H Series Host Name on page 84](#).

## Entering Commands in the CLI

The GigaVUE-OS provides several conventions that make it easy to identify available commands and enter them quickly:

Technique	Description
Context-Sensitive Help	<p>The <b>?</b> symbol is the key to receiving help wherever you are in the CLI:</p> <ul style="list-style-type: none"><li>Type <b>?</b> by itself to see a list of all available commands.</li><li><b>Word Help</b> – Type a partial word with <b>?</b> mark immediately following the partially-typed word to see a list of all possible commands using the word entered so far.</li></ul> <p>For example, if you typed <b>r?</b> in Configure mode, the CLI would return the following possible commands based on what you have entered so far:</p> <pre>radius-server  Configure RADIUS server settings reload         Reboot or shut down the system reset         Reset this system to its factory state</pre> <ul style="list-style-type: none"><li><b>Command Help</b> – Type a command followed by a question mark to see all possible arguments for the command as entered. If the node returns <b>&lt;cr&gt;</b>, that means the command can be entered as-is.</li></ul> <p>For example, if you entered <b>gigastream ?</b>, you would see <b>alias</b>. You can build your way through the entire command tree by entering <b>?</b> after each new argument. For example, after entering <b>gigastream alias myalias ?</b>, you would see the next valid argument – <b>port-list</b>.</p> <p><b>NOTE:</b> Typing <b>?</b> accesses the help system immediately – you do not need to press <b>&lt;Enter&gt;</b>.</p>
Partial Command Entry	<p>For all GigaVUE H Series commands and arguments, you only need to enter enough characters to distinguish the command from all other available commands. So, for example, you do not have to enter the full command <b>debug</b> – there is only one command starting with the letter <b>d</b>, so you only have to enter <b>d</b>.</p>
Command Completion	<p>If you have partially typed a command, you can press <b>Tab</b> and the CLI will attempt to complete the command for you based on what has been entered so far.</p> <p>Use the command completion feature together with partial command entry – you can press <b>Tab</b> while entering a command to see a list of all available commands matching what you have entered so far. For example, you can press <b>p&lt;Tab&gt;</b> and the node will return:</p> <pre>ping  ping6  port  port-group  port-pair  ptp</pre> <p>Based on this information, you know that you only need to enter <b>pt</b> to distinguish the <b>ptp</b> command from the other commands beginning with the letter <b>p</b>.</p>

## Command-Line Syntax – Entering Commands

You enter all configuration commands for the GigaVUE-OS in the command-line interface. Enter commands by typing enough characters to uniquely identify the command and pressing **<Enter>**.

When entering commands, keep in mind the following rules:

- Successful commands return no response in the CLI; commands with errors return an error response beginning with %, followed by a short error description.
- All commands are case-sensitive.
- Aliases are case-sensitive and accept both lower and upper case – for example, **my\_alias** and **My\_Alias** refer to two separate maps.
- The **no** command is used to remove configuration settings. For example **no connect alias myconnect** deletes the named **myconnect**.
- Port numbers are entered in **<chassis-id>/<slot-num>/<port-num>** format. For example, **1/1/x1** identifies the 10Gb/1Gb port x1 in slot 1 on box 1.
- Strings must consist entirely of alphanumeric characters with no spaces. The only exceptions are the underscore (**\_**) and hyphen (**-**) characters. Those are allowed.

For example, in Configure mode, **port 1/1/g1 alias My\_Alias** is legal, but **port 1/1/g1 alias My Alias** is not.

**NOTE:** Some string fields do accept spaces provided the input is made inside quotation marks (for example, the **banner login** command described in [Using a Custom Banner on page 87](#)).

## Configure Mode Syntax

Users of GigaVUE nodes may be accustomed to entering the word **config** before many commands – **config map**, **config port-filter**, and so on. When using the GigaVUE-OS, the “config” part of the command is implied whenever you are working in Configure mode. The system prompt helps you remember this by including the word (**config**) in parentheses. For example:

```
(config) #
```

So, instead of entering **config gigastream** to set up a GigaStream consisting of multiple ports, you just enter **gigastream** followed by the necessary arguments. The **config** part is implied because you are already working in the Configure mode. For example:

```
(config) # gigastream alias mystream port-list 1/1/x1..x4
```




## Paging through CLI Output

By default, the CLI returns output exceeding the configured terminal length in pages. The CLI provides the same features for working through the paged output as the Linux programs **less** and **more**. Press the **h** key when presented with the paging prompt at the base of the display to see paging options – [Figure 4-10 on page 73](#) provides an example of how to do this.


If you prefer, you can disable paging either for the current session or by default:

- **Disable for Current Session**  
(config) # no cli session paging enable
- **Disable for All Sessions (Default)**  
(config) # no cli default paging enable



```
10.150.52.231 - Tera Term VT
File Edit Setup Control Window Help
Map mode: classic
Total Map Count: 46
-----
Map Alias      Type      #Rules  GSOP      collector    Dest Ports
-----
*** Network port: 16/6/g6
    1: ipdst_boxid16_lc6  by-rule  300
*** Network port: 5/6/x6
    1: ipdst_boxid5_lc6   by-rule  300
*** Network port: 10/5/x6
    1: ipsrc_boxid10_lc5  by-rule  300
*** Network port: 16/5/g6
    1: ipsrc_boxid16_lc5  by-rule  300
*** Network port: 5/5/x6
    1: ipsrc_boxid5_lc5   by-rule  300
*** Network port: 7/5/x6
    1: ipsrc_boxid7_lc5   by-rule  300
*** Network port: 8/5/x6
    1: ipsrc_boxid8_lc5   by-rule  300
*** Network port: 10/8/x6
    1: mapdst_boxid10_lc8 by-rule  300
*** Network port: 16/8/g6
    1: mapdst_boxid16_lc8 by-rule  300
*** Network port: 5/8/x6
    1: mapdst_boxid5_lc8  by-rule  300
*** Network port: 7/8/x6
    1: mapdst_boxid7_lc8  by-rule  300
lines 1-26
```

**h**  
When you see the paging prompt at the base of the CLI display, you can press the **h** key to see a summary of the available options.



```
10.150.52.231 - Tera Term VT
File Edit Setup Control Window Help
SUMMARY OF LESS COMMANDS
Commands marked with * may be preceded by a number, N.
Notes in parentheses indicate the behavior if N is given.
h H      Display this help.
q :q Q :Q ZZ  Exit.
-----
MOVING
e AE j ^N CR * Forward one line (or N lines).
y AY k ^K ^P * Backward one line (or N lines).
f AF ^V SPACE * Forward one window (or N lines).
b AB ESC-v    * Backward one window (or N lines).
z            * Forward one window (and set window to N).
w            * Backward one window (and set window to N).
ESC-SPACE    * Forward one window, but don't stop at end-of-file.
d ^D         * Forward one half-window (and set half-window to N).
u ^U         * Backward one half-window (and set half-window to N).
ESC-)        * Left one half screen width (or N positions).
ESC-( LeftArrow * Right one half screen width (or N positions).
F            * Forward forever; like "tail -f".
r ^R ^L      * Repaint screen.
R            * Repaint screen, discarding buffered input.
HELP -- Press RETURN for more, or q when done
```

Figure 4-10: Viewing Paging Options

## The Basic Commands

The following table lists each of the top level commands for the GigaVUE-OS in Configure mode. As described in [Entering Commands in the CLI on page 71](#), the commands available in Configure mode are a superset of those available in Standard and Enable modes.

Most commands have multiple supported arguments. You can see the exact arguments available at any point of command entry by typing it into the CLI followed by `?`.

Table 4-1: CLI Commands

Command	Description
<code>aaa</code>	Configures authentication, authorization, and accounting settings.
<code>apps</code>	Enables access to Gigamon Applications, such as Application Session Filtering (ASF), GTP backup, GTP whitelisting, inline SSL decryption, keystore, NetFlow, SIP whitelisting, and out-of-band SSL decryption. GigaSMART applications are not supported on GigaVUE TA Series.
<code>banner</code>	Sets a node login banner.
<code>bond</code>	Configures bonded interface settings.
<code>boot</code>	Configures node boot parameters.
<code>card</code>	Configures a line card or module.
<code>chassis</code>	Configures the GigaVUE H Series chassis.
<code>clear</code>	Resets statistics or clears caches.
<code>cli</code>	Configures CLI shell options.
<code>clock</code>	Sets the node clock or timezone.
<code>cluster</code>	Configures a cluster of connected GigaVUE-OS nodes.
<code>configuration</code>	Manages configuration files.
<code>configure</code>	Enters Configure mode.
<code>coreboot</code>	Upgrades the BIOS image on GigaVUE-TA100 and GigaVUE-HC1.
<code>crypto</code>	Manages X.509 certificates for the GigaVUE H Series node's Web server.
<code>debug</code>	Generates a dump file for use in debugging issues with Gigamon Technical Support.
<code>disable</code>	Exits Enable mode and returns to Standard mode.
<code>email</code>	Configures email and event notification via email.
<code>enable</code>	Enters Enable mode.
<code>exit</code>	Exits Configure mode and returns to Enable mode or logs out of the CLI.
<code>file</code>	Manages TCP and debug dump files on disk.
<code>filter-template</code>	Configures flexible filter templates on GigaVUE-HC3 and GigaVUE-TA100.
<code>gigasmart</code>	Configures an interface address to a GigaSMART card or module.
<code>gigastream</code>	Configures a GigaStream—a group of ports acting as a single addressable tool port destination or stack-link.
<code>gsgroup</code>	Configures a GigaSMART group consisting of one or more internal GigaSMART ports.

Table 4-1: CLI Commands

Command	Description
<i>gsop</i>	Configures a GigaSMART operation consisting of one or more advanced processing applications.
<i>gsparams</i>	Configures GigaSMART parameters.
<i>halt</i>	Shuts down the node without powering it off.
<i>hb-profile</i>	Configures a heartbeat profile on GigaVUE HC Series nodes.
<i>help</i>	Views a description of the interactive help system.
<i>hostname</i>	Specifies the node's hostname. The hostname appears in the system prompt and in SNMP traps.
<i>ib-pathway</i>	Reserved for future use.
<i>image</i>	Manages node software images.
<i>inline-network</i>	Configures an inline network on GigaVUE HC Series nodes.
<i>inline-network-group</i>	Configures an inline network group on GigaVUE HC Series nodes.
<i>inline-serial</i>	Configures an inline tool series on GigaVUE HC Series nodes.
<i>inline-tool</i>	Configures an inline tool on GigaVUE HC Series nodes.
<i>inline-tool-group</i>	Configures an inline tool group on GigaVUE HC Series nodes.
<i>interface</i>	Configures network interfaces.
<i>ip</i>	Configures IP settings for the eth0 Mgmt port.
<i>ipv6</i>	Configures IPv6 settings for the eth0 Mgmt port.
<i>job</i>	Configures scheduled jobs.
<i>ldap</i>	Configures LDAP server settings for authentication.
<i>license</i>	Activates features using license keys. Licensing is used for GigaSMART, Port, or Advanced Features License.
<i>logging</i>	Configures event logging.
<i>map</i>	Configures maps and map rules to manage GigaVUE traffic distribution.
<i>map-group</i>	Configures map groups for GTP whitelisting and GTP flow sampling.
<i>map-passall</i>	Creates a pass-all map to send all traffic on a network port to a tool port irrespective of the other packet distribution in place on the port.
<i>map-scollector</i>	Configures shared collector map parameters.
<i>map-template</i>	Configures a map template.
<i>nhb-profile</i>	Configures a negative heartbeat on GigaVUE HC Series nodes.
<i>no</i>	Deletes or clears certain configuration options.
<i>notifications</i>	Configures notification settings.
<i>ntp</i>	Enables and disables the use of NTP, as well as adds NTP servers.
<i>ntpdate</i>	Sets node clock once from a remote server using NTP.
<i>pcap</i>	Configures packet capture.
<i>ping</i>	Sends ICMP echo requests to a specified host.

Table 4-1: CLI Commands

Command	Description
<i>ping6</i>	Sends IPMPv6 echo requests to a specified IPv6 host.
<i>pld</i>	Upgrades programmable logic devices (PLDs) on GigaVUE-HC3 nodes.
<i>policy</i>	Configures an active visibility policy.
<i>port</i>	Configures port type, parameters, and filters.
<i>port-group</i>	Creates a group of ports.
<i>port-pair</i>	Configures a port-pair on a pair of network ports within the same GigaVUE H Series node. A port-pair is a bidirectional connection in which traffic arriving on one port in the pair is transmitted out the other (and vice-versa) as a pass-through TAP.
<i>ptp</i>	Enables and disables the use of PTP.
<i>radius-server</i>	Configures RADIUS server settings for authentication.
<i>redundancy-profile</i>	Configures an inline redundancy profile on GigaVUE HC Series nodes.
<i>reload (reboot)</i>	Reboots or shuts down the node.
<i>reset</i>	Resets specified portions of the node configuration to their factory states.
<i>serial</i>	Sets options for the serial console port.
<i>sfp</i>	Reserved for future use.
<i>show</i>	Displays configuration and status information for GigaVUE H Series settings and entities.
<i>sleep</i>	Sleeps for a specified number of seconds.
<i>snmp-server</i>	Configures SNMP settings, including the local SNMP server, notification events, and notification destinations.
<i>spine-link</i>	Configures spine links in a cluster with a leaf and spine architecture.
<i>ssh</i>	Enables and disables SSH access, as well as manages settings.
<i>stack-link</i>	Configures a stack-link between two GigaVUE H Series nodes in a cluster. Stack-links are used to carry data traffic between nodes in a GigaVUE H Series cluster.
<i>sync</i>	Enables dynamic control card synchronization for a GigaVUE-HD8 node.
<i>system</i>	Changes system settings.
<i>system-health</i>	Configures system health behaviors.
<i>tacacs-server</i>	Configures TACACS+ server settings for authentication.
<i>telnet-server</i>	Enables or disables Telnet access.
<i>terminal</i>	Sets terminal parameters, including width and length.
<i>timestamp</i>	Configures the timestamp source.
<i>tool-mirror</i>	Configures a tool-mirror connection between two tool ports. A tool-mirror connection sends all packets arriving on one tool port to a second tool port on the same node.
<i>traceroute</i>	Traces the route packets take to a destination.
<i>tunnel</i>	Reserved for future use.
<i>tunnel-endpoint</i>	Configures a tunnel endpoint, which is a destination for load balanced traffic from a L2GRE encapsulation tunnel.

Table 4-1: CLI Commands

Command	Description
<i>tunneled-port</i>	Configures a tunnel port to be used for GigaSMART encapsulation/decapsulation operations.
<i>uboot</i>	Installs new uboot software.
<i>username</i>	Manages user accounts.
<i>vport</i>	Configures a virtual port.
<i>web</i>	Configures the Web server used for H-VUE GUI support on the GigaVUE H Series node.
<i>write</i>	Saves the running configuration to persistent storage.

## Completing the Initial GigaVUE H Series Setup

At this point, you have logged in to the GigaVUE-OS command-line interface using the **admin** account, configured the **Mgmt** port's network properties for Telnet or SSH access, and have explored the command-line interface structure.

There are a few more steps you should perform to complete the initial configuration before you get to the fun stuff – setting up network ports, tool ports, and mapping traffic. These tasks include:

- Switch to the Configure mode.  
Refer to [Enter the Configure Command-Line Mode on page 78](#).
- Configure Telnet and SSH access to the node.  
Refer to [SSH, Telnet, or Both? on page 78](#).
- Enable the GigaVUE Web server for Web-based GUI access.  
Refer to [Enabling the GigaVUE H Series Web Server on page 80](#).
- Configure some basic user accounts.  
Refer to [Initial User Account Configuration on page 82](#).
- Configure the GigaVUE name.  
Refer to [Configuring the GigaVUE H Series Host Name on page 84](#).
- Configure the GigaVUE time and date options.  
Refer to [Configuring GigaVUE H Series Time Options on page 84](#).
- Configure automatic email notifications for node events.  
Refer to [Configuring Automatic Email Notifications on page 86](#).
- Configure a custom login banner.  
Refer to [Using a Custom Banner on page 87](#).
- Save your changes!  
Refer to [Saving Changes on page 88](#).

## Enter the Configure Command-Line Mode

Keep in mind that the GigaVUE-OS has three different command modes for the CLI – **Standard**, **Enable**, and **Configure**. The commands described in the following sections are all only available in Configure mode. Switch to Configure mode as follows:

Command	Notes
> enable	You only need to supply enough of each command to positively identify it among the other available commands. So, in this example, you could just type <b>ena</b> and press Enter.
# configure terminal	Similarly, this command can be entered as <b>co t</b> .
(config) #	Notice how the system prompt changes with each command mode. Command modes offer greater control over the node as you ascend from <b>Standard</b> to <b>Enable</b> to <b>Configure</b> .

## SSH, Telnet, or Both?

Both Telnet and SSH2 are available for remote connections to the GigaVUE-HC2's **Mgmt** port. By default, SSH2 is enabled and Telnet is disabled. Use the **ssh** and **telnet-server** commands in Configure mode to enable or disable the corresponding connections. To disable the corresponding connection, you include **no** before the command, as demonstrated in the following table. For example:

Command	Notes
<b>Enable:</b> (config) # ssh server enable <b>Disable:</b> (config) # no ssh server enable	When SSH2 is enabled, use any compliant SSH2 client to connect to the command-line interface remotely. For example, to connect using the popular SSH2 client, PuTTY: <ol style="list-style-type: none"><li>Start PuTTY and enter the GigaVUE H Series node's IP address in the Host Name field.</li><li>Click the <b>SSH</b> protocol radio button.</li><li>Click <b>Open</b> to open a connection. If this is your first connection PuTTY warns you that the host key presented by the GigaVUE H Series node is not in your cache. You can add the key, connect without adding the key, or cancel the connection. Refer to <a href="#">Verifying Host Keys During Connection on page 79</a> for information on how to verify that the host key shown is the correct one.</li><li>Log in with GigaVUE credentials.</li></ol>
<b>Enable:</b> (config) # telnet-server enable <b>Disable:</b> (config) # no telnet-server enable	When Telnet is enabled, use any compliant Telnet client to connect to the command-line interface remotely. For example, to connect using the Telnet client provided with Microsoft Windows: <ol style="list-style-type: none"><li>Open a command prompt window and type <b>Telnet</b>.</li><li>Type <b>open &lt;Mgmt Port IP Address&gt;</b>.</li><li>Log in with GigaVUE credentials.</li></ol>

## Advantages of SSH2

SSH2 is a more secure choice for remote connections than Telnet, providing an encrypted channel instead of relying on clear text. It also provides stronger user authentication capabilities, including the use of a public *host key*. Host keys uniquely identify a server, helping guarantee that the server you are connecting to is the server you think it is.

GigaVUE includes default RSA v1/v2 and DSAv2-encrypted public host keys (SSH2 supports both RSA and DSA encryption algorithms). The first time you connect to GigaVUE with an SSH2 client, the client will warn you that the host keys are not in your local cache and show you the actual host key presented by the GigaVUE-HC2. Your client will most likely give you the option of trusting the key, adding it to your local cache. Once you have trusted the key, your client will alert you during connection if a different key is presented.

## Verifying Host Keys During Connection

To verify that the host key presented during an SSH2 connection is in fact the GigaVUE node's, you can connect over the console port (refer to [Access the Command-Line Interface over the Console Port on page 37](#)) and use the **show ssh server host-keys** command to see the current public host keys and fingerprints for the GigaVUE-HC2. Paste these in a file and keep them nearby when you connect via SSH2 the first time. This way, you will be able to compare the actual host key to what your SSH2 client says is being presented. Once you have verified that they are the same, you can choose to trust the host key, allowing future connections to take place seamlessly.

## Changing Host Keys

Use the **ssh server host-key generate** command to change the default host keys provided with the GigaVUE-HC2. The command has the following syntax:

```
ssh server host-key <rsa1 | rsa2 |dsa2> <private-key | public-key> generate
```

For example, to configure a new RSAv1 public hostkey, you could use the following command:

```
(config) # ssh server host-key rsa1 public-key generate
```

## Enabling the GigaVUE H Series Web Server

H-VUE is Gigamon's Web-based management interface for the GigaVUE H Series. Use H-VUE or GigaVUE-FM for many node configuration, management, and operations tasks.

To use H-VUE with a GigaVUE H Series node, you must enable its Web server with the **web enable** command. For example:

```
(config) # web enable
```

Check the status of the Web server using the **show web** command. Make sure that **Web-based management console enabled:** is set to **yes**, indicating that the Web server is enabled. For example:

```
(config) # show web
Web-based management console enabled: yes

HTTP enabled:                yes
HTTP port:                   80
HTTP redirect to HTTPS:     yes
HTTPS enabled:               yes
HTTPS port:                  443
Require certificates from DoD CA: no
HTTPS certificate name:      default-cert
Listen enabled:             yes
No Listen Interfaces.

Inactivity timeout:         15 min
Session autologout:        2 hr 30 min
Session renewal:           30 min

Web client (for file transfers)
Proxy enabled: no
HTTPS server cert verify: yes
HTTPS supplemental CA list: default-ca-list
```

Once the Web server is enabled, you can use H-VUE for GigaVUE H Series connections, as described in [Connecting to the GigaVUE H Series Node from H-VUE on page 80](#). Refer to the *GigaVUE-OS CLI Reference Guide* for information on other Web server settings you can configure.

## Connecting to the GigaVUE H Series Node from H-VUE

After you enable the Web server on the GigaVUE H Series node, it automatically listens for connections from H-VUE using either HTTP on port 80 or HTTPS on port 443. Use the following procedure to connect to a GigaVUE H Series node using H-VUE.

**NOTE:** You can configure whether the GigaVUE H Series node redirects all incoming HTTP connections to the HTTPS port with the **web http redirect** command.

1. Open a supported browser. Refer to the *GigaVUE-OS H-VUE User's Guide*.



2. Enter one of the following URLs:
  - https://<GigaVUE Node IP Address>
  - http://<GigaVUE Node IP Address>
3. The first time you connect to H-VUE, your browser will prompt you regarding an invalid security certificate. Depending on the browser you are using, you can avoid these warnings either by installing a certificate or adding an exception. The following table has the details:

Browser	Add Exception?	Install Certificate?
Mozilla Firefox	Y	Y
Windows Internet Explorer	N	Y

**NOTE:** Gigamon provides the GigaVUE H Series with self-signed certificates for use with H-VUE; you can also create and install a third-party certificate on these nodes.

Add an exception in Firefox as follows:

- a. Click the **Or you can add an exception** link.
- b. Click the **Add Exception** button.
- c. Click the **Get Certificate** button.
- d. Click the **Confirm Security Exception** button.

The H-VUE login page appears.

4. Enter a valid user name and password and click **Login**.

#### Configuring Internet Explorer for Use with H-VUE

H-VUE works best in Internet Explorer when the browser is configured to check for newer versions of stored pages every time pages are visited. Enable this option as follows:

1. Open Internet Explorer.
2. Select the **Tools > Internet Options** command.
3. In the **General** tab, locate the **Browsing history** section and click its **Settings** button.
4. Set the **Check for newer version of stored pages:** option to **Every time I visit the webpage**.
5. Click **OK** on the Temporary Internet Files and History Settings dialog.
6. Click **OK** on the Internet Options dialog.

#### Next Steps?

Refer to the online help for details on configuring and operating the GigaVUE-HC2 from the H-VUE interface. Keep in mind that each of the initial configuration settings described in the rest of this chapter can also be set in H-VUE.

## Initial User Account Configuration

Before you start mapping traffic, you must change the password for the **admin** account and add a few other accounts for use by different level users. (You may have already used the jump-start script to change the password for the **admin** account.)

### Changing the admin Account Password

1. To change the password for the **admin** account using the **username** command, refer to the following:

```
(config) # username admin password <password>
```

Passwords must meet the following standards:

- Include 8-30 characters.
- Include at least one numeral
- Include at least one capital letter
- Include at least one special character (for example, !, @, #, \$, %, ^, &, or \* – ASCII 0x21, 0x2F, 0x3A, 0x40, 0x5B, 0x5F, 0x7B, 0x7E).

Enter a new password that meets the standards and confirm the password.

### Setting Up Some Basic Accounts

1. Next, you will probably want to set a few user accounts with different access levels.

The GigaVUE H Series node has a local account database that can optionally integrate with an LDAP, RADIUS, or TACACS+ server for authentication. Any account you want to authenticate using an external AAA server must have a matching account name in the local database.

Authentication, user levels, and roles are discussed in detail in the *GigaVUE-OS CLI Reference Guide*. For now, however, it is easiest to simply create a few basic user accounts with different privilege levels. In general, user privileges are as follows:

- **Admin** users have access to all command modes, including Standard, Enable, and Configure. They also have full permissions for all network, tool, and stack ports.
- **Operator** users have access to all command modes, including Standard, Enable, and Configure. However, they only have access to the network and tool ports associated with their user group.

New users are created with the operator role by default. You can add additional roles with the **username <username> roles add <roles>** command.

- **Monitor** users have access to the Standard and Enable command modes. They cannot configure packet distribution (or any other global GigaVUE H Series node options), but they can use the **show** command to review many of the settings in place on the node.

The following **username** commands create a new **admin** user and a new **operator** user:

Command	Comments
(config) # username psandoval password Nine9.Eight8! (config) # username psandoval roles add admin	Creates a new account named <b>psandoval</b> with a password, and grants it admin privileges.
(config) # username bcrawford password Seven7.Six6!	Creates a new account named <b>bcrawford</b> with a password. New users are automatically created with default operator level privileges, so there is no need to grant an additional role.

2. Once you have configured these basic user accounts, use the **show usernames** and **show roles** commands to review your settings.

## Configuring the GigaVUE H Series Host Name

It is generally a good idea to configure the GigaVUE H Series node's name, date, and time as part of your initial configuration. The following command shows how to set the node name. Refer to [Configuring GigaVUE H Series Time Options on page 84](#) for information on setting options related to time and date.

### Setting the Node Name

1. Use the **hostname** command to specify the node name. For example:  

```
(config) # hostname GigaVUE-QA
```

## Configuring GigaVUE H Series Time Options

The GigaVUE H Series node includes a variety of features for setting the time, including:

Method	CLI Command	For more information:
System Clock	<code>clock set hh:mm:ss yyyy/mm/dd</code>	<a href="#">Setting Time Manually on page 59</a>
One-Time NTP Synchronization	<code>ntpdate &lt;ntpserver address&gt;</code>	<a href="#">Performing One-Time NTP Server Synchronization on page 60</a>
Persistent NTP Synchronization	Add server using <code>ntp server</code> command. Enable use of ntp with <code>ntp enable</code> command.	<a href="#">Using NTP Time Server for Clock Synchronization on page 60</a>
PTP Synchronization	Enable PTP with <code>ptp enable</code> command.	<a href="#">GigaVUE-OS CLI Reference Guide</a>

### Setting Time Manually

The easiest way to set the GigaVUE H Series node's time is manually with the **clock set** command. For example:

```
(config) # clock set 05:18:38 2015/01/06
```

**NOTE:** Even if you are using NTP, configure time manually as well. The GigaVUE H Series node will automatically fall back to the manual time setting if it is unable to synchronize with the specified time server.

The **show ntp** will show the current state of the NTP server in use; the **show clock** command shows the current GigaVUE H Series node's time.

### Performing One-Time NTP Server Synchronization

You can perform a one-time synchronization with an NTP server using the **ntpdate** command. For example:

```
(config) # ntpdate time.nist.gov
```

**NOTE:** This method does not provide updates to correct clock drift over time. It is generally preferable to use persistent NTP synchronization with the **ntp** commands.

## Using NTP Time Server for Clock Synchronization

The GigaVUE H Series node can optionally use one or more NTP servers for its time setting. Use the following procedure to add an NTP server to the GigaVUE H Series node's list and enable the use of NTP.

1. Specify the address of the time server. For example, if the time server is on 192.168.1.10, you would use the following command:

```
(config) # ntp server 192.168.1.10
```

**NOTE:** There are many public NTP servers available on the Internet.

2. Turn on NTP with the following command:

```
(config) # ntp enable
```

3. The GigaVUE H Series node connects to the specified NTP server and synchronizes to its time.

4. NTP reports times in UTC. Because of this, it is a good idea to specify the GigaVUE H Series node's timezone so that UTC can be converted to the local timezone.

You specify the timezone either in terms of the offset from UTC (either plus or minus) or with a particular location's name, depending on the argument you choose for the **clock timezone** command:

- **Offset from UTC** – Set the timezone as an offset from UTC with the **UTC-offset** argument. For example, the following command sets the timezone as eight hours earlier than UTC:


```
(config) # clock UTC-offset UTC-8
```

- **Location** – You can specify a particular location's timezone to use. The easiest way to do this is to build the available list of cities by adding a space and a question mark after each subsequent zone word. For example, enter **(config) # clock timezone ?** to see the list of available locations. Select a location and use the same question mark technique to see the next available zone words. This way, you can build out to the exact location you need. For example:

```
(config) # clock timezone America North United_States Pacific
```

```
(config) # clock timezone Asia Eastern Hong_Kong
```

Once you have finished configuring NTP options, use the **show ntp** command to check the status of clock synchronization (Figure 4-11).



The screenshot shows a terminal window titled "GigaVUE - 192.168.1.159 VT". The terminal output is as follows:

```
GigavUE (config) # show ntp
NTP is enabled.
Clock is synchronized. Reference: 69.25.96.13. Offset: -4.846 ms.
Active servers and peers:
-----
Address          Status      Stratum    offset  Ref    Poll  Last
                (msec)    clock      (sec)   (sec)
-----
69.25.96.13      sys.peer (*) 1          -4.846 .ACTS. 64     24
GigavUE (config) #
```

Figure 4-11: Checking NTP Status and Configuration

## Configuring Automatic Email Notifications

The GigaVUE H Series node provides powerful email notification capabilities, automatically sending emails to specified addresses when any of a wide variety of events take place on the node. Gigamon strongly recommends that you configure this feature so you have immediate visibility of events affecting node health.

You configure automatic email notifications with the **email** command and its arguments. Start by making sure the CLI is in Configure mode. If the **(config)** entry appears in the system prompt, you are in Configure mode. If not, use the **enable** and **configure terminal** commands sequentially to change to Configure mode. Then, configure email notifications as follows:

Description	Command
First, use the <b>email mailhub</b> command to specify the mail server to use for notification emails. In this example, we are using the email server named <b>smtp.emailsrvr.com</b> . You could also supply an IP address instead of a hostname.	<b>(config) # email mailhub smtp.emailsrvr.com</b>
Next, use the <b>email auth</b> command to supply the email account username and password. In this example, we are using <b>alerts@mycompany.com</b> with a password of <b>mypassword123</b> .	<b>(config) # email auth username alerts@mycompany.com</b> <b>(config) # email auth password mypassword123</b>
Now that we have set up the account to use, we will turn on email authentication.	<b>(config) # email auth enable</b>
Now that we have configured the settings that let the node send emails, set up who to send them to and when to send them. Use <b>email notify recipient</b> to configure the destinations for event notification emails. You can specify multiple destinations separated by commas with no spaces.	<b>(config) # email notify recipient</b> <b>cday@mycompany.com,mfelton@mycompany.com</b>
The <b>email notify event</b> command lets you configure which events will trigger automatic emails. There are quite a few events available – start by entering <b>email notify event ?</b> to see the list of available events. You can either enable individual events, or, use the <b>all</b> argument to enable them all. We are going to start with the <b>all</b> setting and tune settings as necessary later on.	<b>(config) # email notify event all</b>
It is a good idea to check your settings and make sure emails are sent successfully. You can do that with the <b>email send-test</b> command. If you do not receive the email, check the <b>show log</b> output to make sure the email was sent. Then, reconfigure email settings, if necessary.	<b>(config) # email send-test</b>
You may also want to configure and enable <b>autosupport</b> emails. Autosupport emails are sent directly to Gigamon's Technical Support department when specified events take place, enabling proactive problem resolution. The GigaVUE H Series node is preconfigured with the correct destination address – you just need to enable the feature with the following command.  Use <b>show email events</b> to see the list of events for which autosupport emails will be sent. You can change the list with the <b>(no) email autosupport event</b> command.	<b>(config) email autosupport enable</b>

## Description

## Command

Emails will now be sent automatically to the configured addresses when any of the selected events take place.

There are many other options for fine-tuning automatic email settings, including how to handle “dead letters” (emails that did not reach their recipient), how the email address of the GigaVUE H Series node should appear, the port for the email server, the reply-to address, and so on. Refer to the *GigaVUE-OS CLI Reference Guide* for details.

---

## Using a Custom Banner

The GigaVUE H Series node can display a customizable text banner at node startup before a user logs in. This way, users connecting to the node see the banner before they log in, giving them an idea of which node they are logging in to. The banner also appears after a user logs out.

Use the **banner login** “<string>” command to configure the login banner. For example:

```
(config) # banner login "Pacific Call Center"
```

**NOTE:** You only need to use quotation marks for the <string> if it includes spaces.


The next time you log in or out of the GigaVUE H Series node, you will see the customizable banner.

## Saving Changes

It is a good idea to use the **write memory** command to save changes as you make them. Later on, when you start setting up packet distribution with connections and maps, your changes will be added to the active configuration right away but will not be saved across a node reboot unless you use the **write memory** command to save your changes to flash.

**NOTE:** The name of the factory-provided configuration file is **initial**. You can see the name of the most recently booted configuration file by using the **show running-configuration** command (or **show configuration**) and look for the **## Running database** entry. In [Figure 4-12](#), you can tell that the GigaVUE H Series node is currently operating with the **initial** configuration file.

Refer to the *GigaVUE-OS CLI Reference Guide* for details on using configuration files.



```
10.150.52.231 - Tera Term VT
File Edit Setup Control Window Help
qaChassis10 [8649: master] (config) # show conf run
##
## Running database "initial"
## Generated at 2013/03/19 10:28:28 +0000
## Hostname: qaChassis10
##
##
## Network interface configuration
##
interface eth0
  create
  comment ""
  no dhcp
  display
  duplex auto
  ip address 10.150.52.12 /24
  mtu 1500
  no shutdown
  speed auto
  no zeroconf
  exit
##
## Network interface IPV6 configuration
##
interface eth0
  no ipv6 address autoconfig
  ipv6 address autoconfig default
  no ipv6 address autoconfig privacy
  no ipv6 dhcp client enable
  ipv6 enable
  exit
```

Figure 4-12: Showing the Current Configuration File



## Connecting GigaVUE-HC2 Ports

---

This chapter describes transceivers and port connections. In general, connecting GigaVUE-HC2 module ports to the network is as simple as installing a transceiver and connecting the correct cable to data sources or destinations. Refer to the following sections for details:

- [Transceiver—Rules and Notes on page 89](#)
- [BiDi Optics Considerations on page 90](#)
- [Transceiver Installation Instructions on page 90](#)
- [Fiber TAP Specifications on page 91](#)
- [Bypass Combo Module Specifications on page 91](#)
- [Cabling on page 94](#)
- [Connecting GigaVUE-HC2 Module Ports on page 94](#)

---

### Transceiver—Rules and Notes

Keep in mind the following rules and notes when you connect and use GigaVUE-HC1 nodes with transceivers:

- Always use transceivers purchased from Gigamon to ensure interoperability and performance. Gigamon does not support transceivers purchased from other vendors.
- After removing an optical transceiver, the best practice is to wait ten (10) or more seconds before re-inserting the same or different optical transceiver.
- Use the **show port params all** command to see transceiver type information for each of the network/tool ports in the GigaVUE-HC2 node. Check the value of the **SFP type** field for the ports in question.
- Following are the nomenclatures for the GigaVUE-HC2 node port numbers:
  - Port numbers starting with c (for example, c1) are 100Gb.
  - Port numbers starting with q (for example, q1) are 40Gb.
  - Port numbers starting with x (for example, x10) are 10Gb or 1Gb depending on the transceiver installed.

- For details about the supported transceivers, cable types, and connectivity specifications, refer to “*GigaVUE-OS Compatibility and Interoperability Matrix*”.

---

## BiDi Optics Considerations

There are several nuances to consider due to the complexity in 40Gb BiDi technology.

Because of the nature of 40Gb BiDi technology, the same BiDi optic (Full Duplex or RX-only) cannot be used in all of the following situations. For example:

- On SPAN sessions, RX-only BiDi optics cannot be used. Full Duplex BiDi optics must be used.
- When receiving traffic from network links, RX-only BiDi optics must be used due to the way traffic is multiplexed over the fiber pair in 40Gb BiDi technology.
- When deploying over inline 40Gb BiDi links, Full Duplex BiDi optics must be used.
- When connecting two GigaVUE nodes through a cascade connection, Full Duplex BiDi optics must be used for the tool port. The network port may be either Full Duplex or RX-only BiDi optics.
- When stacking multiple GigaVUE nodes, 40Gb BiDi optics must not be used on stack links because the 40Gb BiDi technology is not compatible with the Gigamon stack protocol.

---

## Transceiver Installation Instructions

Gigamon transceivers are keyed and can only be installed in one direction.

Transceivers are hot-swappable – they can be installed or removed with the power on or off. Use the following procedures to install and remove SFPs from GigaVUE modules.

**IMPORTANT:** Always use an ESD-preventive wrist or ankle strap and ensure that it makes good skin contact when installing or removing SFP/SFP+ transceivers. The strap can be connected to one of the following:

- ESD wrist strap connector. The GigaVUE-HC2 chassis provides a connector at the front of the chassis for this purpose labeled **ESD GND PT**.
- Captive installation screws on an installed module or power supply.
- Any unpainted surface on the chassis.

### Installing Transceivers

1. Remove the dust cap from the port and set it aside for future use.
2. Orient the transceiver with the opening in the module and insert it into the slot.
3. Push gently but firmly until the transceiver is seated in the slot.
4. Close the latch on the SFP to lock it into the slot.

## Removing Transceivers

1. Disconnect the cable (if any) from the transceiver.
2. If you are removing a fiber-optic transceiver, install dust caps in the transceiver to protect the optical interfaces.
3. Open the latch on the transceiver and gently remove it from the slot.
4. If you are not installing a new transceiver, install a dust cap in the open slot on the module.

## Fiber TAP Specifications

Refer to [Table 5-1](#) and the “*Transceiver and Cable Matrix for GigaVUE-H Series Fiber TAP Modules*” section in the *GigaVUE-OS Compatibility and Interoperability Matrix* for specifications for Fiber TAPs, including internal transceiver specifications and loss summaries.

Table 5-1: Internal Transceiver Specifications for Fiber TAPs

Module Type	Transceiver Type	Speed	Auto Negotiation	Duplex
<b>TAP-HC2-D25AC0 SX/SR 50/125 12 TAP Module</b>	N/A	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>TAP-HC2-D25BC0 SX/SR 62.5/125 12 TAP Module</b>	N/A	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>TAP-HC2-D35CC0 LX/LR 12 TAP Module</b>	N/A	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>TAP-HC2-G100C0 Copper (RJ-45) 12 TAP Module</b>	N/A	1000Mbps (1Gbps)	Always ON	Full

## Bypass Combo Module Specifications

Refer to [Table 5-2](#) and [Table 5-3](#) for specifications for bypass combo modules, including internal transceiver specifications and loss summaries.

Table 5-2: Internal Transceiver Specifications for Bypass Combo Modules

Module Type	Transceiver Type	Speed	Auto Negotiation	Duplex
<b>BPS-HC0-D25A4G SX/SR 50/125 Bypass Combo Module</b>	SFP+ 1Gb/10Gb Dual Rate 850nm MM	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>BPS-HC0-D25B4G SX/SR 62.5/125 Bypass Combo Module</b>	SFP+ 1Gb/10Gb Dual Rate 850nm MM	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>BPS-HC0-D35C4G LX/LR Bypass Combo Module</b>	SFP+ 1Gb/10Gb Dual Rate 1310nm SM	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full
<b>BPS-HC0-Q25A28 SR4 50/125 Bypass Combo Module</b>	SFP+ 1Gb/10Gb Dual Rate 850nm MM	10000Mbps (10Gbps)/ 1000Mbps (1Gbps)	Always OFF	Full

Table 5-3: Loss Summary per Bypass Combo Modules

Type	@	Operating Wavelength (nm)			Cable Type	Max Fiber Length	Max Receiver Sensitivity	Insertion Loss (dB)
		Min	Typical	Max				LC to LC or Port to Port
<b>BPS-HC0-D25A4G SX/SR 50/125</b>	<b>1Gb</b>	840	850	860	LC	550m	-17	2
	<b>10Gb</b>	840	850	860	LC	82m	-11.1	2
<b>BPS-HC0-D25B4G SX/SR 62.5/125</b>	<b>1Gb</b>	840	850	860	LC	275m	-17	2
	<b>10Gb</b>	840	850	860	LC	33m	-11.1	2
<b>BPS-HC0-D35C4G LX/LR</b>	<b>1Gb</b>	1260	1310	1355	LC	10km	-19	2
	<b>10Gb</b>	1260	1310	1355	LC	10km	-12.6	2
<b>BPS-HC0-Q25A28 SR4 50/125</b>	<b>40Gb</b>	840	850	860	MPO/MTP	100m	-13	1

## Module Transceiver Support

Refer to [Table 5-4](#) for transceiver support for GigaVUE-HC2 modules.

Table 5-4: Transceiver Support for GigaVUE-HC2 Modules

Module Type	Transceiver Type	Speed	Auto Negotiation	Duplex
PRT-HC0-C02	QSFP28	100000Mbps (100Gbps)	Always OFF	Full


## Cabling

Refer to the following section or documents for cabling:

- [MPO/MTP 12 Position Fiber Cable for Use with SR4 Transceivers on page 94](#)
- For details about the supported transceiver, cable type, and connectivity specifications, refer to “[GigaVUE-OS Compatibility and Interoperability Matrix](#)”.
- For details about how to cable GigaVUE nodes, refer to “[GigaVUE-OS Cabling Quick Reference Guide](#)”.

### MPO/MTP 12 Position Fiber Cable for Use with SR4 Transceivers

This is a female to female Multi-fiber Push On (MPO) / Ultra Polished Connector (UPC) of cable type B. The following figure provides cabling details for MPO/MTP 12 position fiber cable for use with 40Gb SR4 QSFP+, 40Gb ESR4 QSFP+, and 100Gb SR4 QSFP28 transceivers on GigaVUE-HC2 modules.



## Connecting GigaVUE-HC2 Module Ports

Connecting network and tool ports on GigaVUE-HC2 modules is generally as simple as connecting a cable between the source/destination device and the GigaVUE-HC2 module port. You just need to make sure that the modules and ports on the GigaVUE-HC2 node are enabled and their parameters are configured correctly. Refer to the following sections for details:

- [Enabling Modules and Ports on page 77](#) – Make sure that the modules and ports you want to use are enabled. Newly installed modules must be configured with the **card** command and their ports enabled with **port <port-list> params admin enable**.
- [Setting Port Parameters Manually on page 79](#) – If both ends of the connection are using autonegotiation, no manual configuration is typically necessary. However, if

autonegotiation is not used (or is not successful), you can use these instructions to configure port parameters manually.

## Enabling Modules and Ports

Use the following procedure to ensure that all modules are configured and ports enabled:

1. Connect to console port as described in [Access the Command-Line Interface over the Console Port on page 69](#).

2. Wait at least two minutes after the system prompt appears and then switch to **Configure** mode.

The GigaVUE-HC2 node provides three command entry modes, each with increasingly powerful rights – **Standard**, **Enable**, and **Configure**. Module and port configuration commands are only available in Configure mode:

a. Type **en** <Enter> to switch to Enable mode.

The system prompt changes from **[hostname] >** to **[hostname] #**.

b. Type **config t** <Enter> to switch to Configure mode.

The system prompt changes from **[hostname] #** to **[hostname] (config) #**.

3. Use the following command to check module status:

```
(config) # show cards
```

4. Check the values in the **Config Status** and **Oper Status** columns for all modules and verify that they read **Yes** for configured and **Up** for inserted. This is your indication that the node is ready for further configuration.

5. If the **Config Status** does not show **Configured** for all modules after two minutes, take the action corresponding to your **show cards** output, as follows:

show cards Output:	Corrective Action
<b>Config Status</b> does not show <b>Configured</b> for any cards (including control cards)	<pre>(config) # chassis box-id &lt;integer&gt;</pre> <pre>(config) # card all</pre>
<b>Config Status</b> shows <b>Configured</b> for control cards but not one or more modules	<pre>(config) # card slot x</pre> <p><b>NOTE:</b> If all modules are unconfigured, you can also use the <b>card all</b> command. If some cards are already configured, however (for example, because you just installed a new card), it is better to use <b>slot x</b> for the unconfigured cards.</p>

The **card** command initializes unconfigured module. However, it can only be used after the node's box ID has been configured, as reported at the top of the **show cards** output in [Figure 5-1 on page 96](#).

6. Use the **show cards** command again to verify the following:

- **Box ID** is not empty.
- **Config Status** shows **configured** for all modules.
- **Oper Status** shows **up** for all modules.

Figure 5-1 on page 96 highlights the **show cards** output for a node with properly configured modules.

```
(config) # show cards box-id 1
```

```
Box ID: 1
Slot  Config  Oper Status      HW Type          Product Code    Serial Num    HW Rev
-----
ccl   yes      up              HC2-Main-Board-v2  132-00C2       1AN0-0017    3.3-24
1     yes      up              BPS-HC0-D25B4G    132-00BF       1BF0-0036    2.0-1
2     yes      up              PRT-HC0-X24       132-00BD       1BD0-0064    A0-a2
3     yes      up              TAP-HC0-G100C0    132-00B3       1B30-0080    B0-a8
4     yes      up              PRT-HC0-X24       132-00BD       1BD0-0056    2.3-a2
```

Figure 5-1: Successful show cards Output

7. Use the **port** command with the **admin** argument to enable the ports on the module. For example, the following two commands enable all ports on a PRT-HC0-X24 module:

```
(config) # port 1/1/x1..x24 params admin enable
```

8. Save your changes so that the modules and ports come up automatically at the next reboot:

```
(config) # write memory
```

## Setting Port Parameters Manually

If autonegotiation is not enabled on the other end of the connection, you must manually configure the **port params** of the GigaVUE-HC2 module port to match, followed by a **write** to save the current settings.

The **port params** commands are available in the Configure mode. The syntax is as follows:

```
port <port-list> params
  admin <disable | enable>
  autoneg <disable | enable>
  discovery <cdp | lldp | all | disable>
  duplex <full>
  forcelinkup <disable | enable>
  speed <10 | 100 | 1000 | 10000>
```

The following table summarizes these options:

Argument	Description
<b>admin &lt;disable   enable&gt;</b>	Enables/disables ports administratively. Use the <b>show port params</b> command to see which ports are enabled and disabled.  Refer to <a href="#">Forcelinkup and Enabling/Disabling Ports on page 80</a> for a summary of how this argument interacts with the <b>admin</b> argument.



Argument	Description
<b>autoneg</b> <disable   enable>	<p>Enables and disables autonegotiation for a port. When autonegotiation is enabled, duplex and speed settings are ignored (they are set via autonegotiation).</p> <p>Refer to <a href="#">Forcelinkup and Enabling/Disabling Ports on page 80</a> for a summary of how this argument interacts with the <b>admin</b> argument.</p> <p><b>NOTE:</b> Autonegotiation is always disabled for 10Gb ports.</p> <p><b>NOTE:</b> For 1Gb speeds over copper, autonegotiation must be enabled, per the IEEE 802.3 specification. Gb optical ports cannot enable autoneg.</p>
<b>discovery</b> <cdp   lldp   all   disable>	<p>Configures port discovery options, as follows:</p> <ul style="list-style-type: none"> <li>• cdp—Enables CDP port discovery.</li> <li>• lldp—Enables LLDP port discovery.</li> <li>• all—Enables all port discovery protocols (meaning both CDP and LLDP).</li> <li>• disable—Disables port discovery.</li> </ul> <p>Discovery is disabled by default. To enable discovery, configure one or more protocols.</p>
<b>duplex</b> <full>	<p>Specifies the port's duplex configuration. Only full duplex is supported.</p> <p>Starting in software version 5.2, half duplex support is removed from all GigaVUE nodes. If half duplex was configured in a previous software version, it will remain intact following the upgrade to 5.2 or higher release. Update to full duplex, if required.</p>
<b>forcelinkup</b> <disable   enable>	<p>Forces connection on an optical port. Use this option when an optical tool port is connected to a legacy optical tool that does not transmit light.</p> <p>Available as follows:</p> <ul style="list-style-type: none"> <li>• Optical 1Gb/10Gb tool ports</li> <li>• Not available for 10Gb-capable ports with a 1Gb SFP installed. 10Gb-capable optical tool ports only support <b>forcelinkup</b> when a 10Gb SFP+ is installed.</li> </ul>
<b>speed</b> <10   100   1000   10000>	Sets the port speed in Mbps if autonegotiation is off.

## Autonegotiation and External Fiber TAPs

When connecting a fiber port on the GigaVUE-HC2 node to an external TAP, autonegotiation is disabled on the node's fiber port, and cannot change.

## Forcelinkup and Enabling/Disabling Ports

The GigaVUE-HC2 node includes both **forcelinkup** and **admin** arguments for the **port params** command. The **forcelinkup** argument forces the link state on an optical tool port connected to a legacy tool that does not transmit the light required to bring the link up. The following table summarizes how traffic flows for different combinations of **port params admin** and **port params forcelinkup** applied to an optical tool port.

	forcelinkup = disable	forcelinkup = enable
admin = enable	No traffic passed if autonegotiation is not successful.	Traffic is passed.
admin = disable	No traffic passed.	No traffic passed.



# A GigaVUE-HC2 Specifications

This appendix provides the physical specifications, power requirements, and environmental specifications for GigaVUE-HC2 nodes. Compliance for safety, emissions, and immunity are also provided.

Refer to the following sections for details:

- [Physical Dimensions and Weight on page 99](#)
- [Power Requirements on page 100](#)
- [Environmental Specifications on page 100](#)
- [Standards and Protocols on page 101](#)
- [Compliance on page 101](#)
- [Warranty on page 103](#)

## Physical Dimensions and Weight

The following table summarizes the dimensions and weight for the GigaVUE-HC2 nodes and its modules:

Node	Height	Width	Depth	Weight
GigaVUE-HC2 (w/ 2 power supply + fan + Control Card)	2RU 3.5in (8.9cm)	19.0in (48.3cm)	24.2in (61.6cm) without cable management 27.0in (68.6cm) with cable management	36.80lb (16.70kg)
PRT-HC0-X24 24 x 10Gb Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	2.12lb (0.96kg)
PRT-HC0-Q06 6 x 40Gb Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	2.40lb (1.09kg)
PRT-HC0-C02 2 x 100Gb Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	2.30lb (1.04kg)
TAP-HC0-D25AC0 SX/SR 50/125 12 TAP Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	3.50lb (1.59kg)

Node	Height	Width	Depth	Weight
TAP-HC0-D25BC0 SX/SR 62.5/125 12 TAP Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	3.50lb (1.59kg)
TAP-HC0-D35CC0 LX/LR 12 TAP Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	3.50lb (1.59kg)
TAP-HC0-G100C0 Copper (RJ-45) 12 TAP Module	1.6in (4.1cm)	8.0in (20.3cm)	9.4in (23.8cm)	3.20lb (1.45kg)
SMT-HC0-R GigaSMART Rear Module	1.6in (4.1cm)	9.3in 23.5cm	13.2in (33.6cm)	4.40lb (2.00kg)
SMT-HC0-X16 GigaSMART Front Module	1.6in (4.1cm)	8.0in (20.3cm)	10.2in (26.0cm)	4.40lb (2.00kg)
BPS-HC0-D25A4G BPS-HC0-D25B4G BPS-HC0-D35C4G Bypass Combo Modules	1.6in (4.1cm)	8.0in (20.3cm)	10.5in (26.7cm)	3.60lb (1.63kg)
BPS-HC0-Q25A28 Bypass Combo Module	1.6in (4.1cm)	8.0in (20.3cm)	10.5in (26.7cm)	3.14lb (1.42kg)

## Power Requirements

The following table summarizes the electrical characteristics of GigaVUE-HC2 nodes.

**NOTE:** Refer to [Figure 4-4 on page 59](#) for instructions on how to connect DC power supplies.

Power Specification	Specification
<b>Power Configurations</b>	1+1 Power: 2 Power Supply Modules
<b>Max Power Consumption/Heat Output</b>	<ul style="list-style-type: none"> <li>960 Watts; 3276 BTU/hr (Control Card version 1)</li> <li>960 Watts; 3276 BTU/hr (Control Card version 2)</li> <li>Fully populated system with all ports at 100% traffic load</li> </ul>
<b>AC Power Supply Modules</b>	<ul style="list-style-type: none"> <li>Min/Max Voltage: 100V–240V AC, 47-63Hz</li> <li>Max PSM Input Current: 14A @ 100V</li> </ul>
<b>DC Power Supplies</b>	<ul style="list-style-type: none"> <li>Min/Max Voltage: -36V to -72V DC</li> <li>Max PSM Input Current: 35A @ -36V</li> </ul>

## Environmental Specifications

The following table summarizes the environmental specifications for GigaVUE-HC2 nodes.

Specification	GigaVUE-HC2 Node
Operating Temperature	32°F to 104°F (0°C to 40°C)
Operating Relative Humidity	20% to 80%, non-condensing
Recommended Storage Temperature	-4°F to 158°F (-20°C to 70°C)
Recommended Storage Relative Humidity	15% to 85%, non-condensing
Altitude	Up to 15,000ft (4.6km)

## Standards and Protocols

IEEE 802.3-2012, IEEE 802.1Q VLAN, IEEE 802.3 10BASE-T, IEEE 802.3u 100BASE-TX, IEEE 802.3ab 1000BASE-T, IEEE 802.3z 1000BASE-X, IEEE 802.3ae 10000BASE-X, IEEE 802.3ba, RFC 783 TFTP, RFC 791 IP, RFC 793, TCP, RFC 826 ARP, RFC 854 Telnet, RFC 768 UDP, RFC 792 ICMP, SNMP v1/v2c, RFC 2131 DHCP client, RFC 1492 TACACS+, and support for IPv4 and IPv6.

## Compliance

This section provides compliance information for GigaVUE-HC2.

### Safety

GigaVUE-HC2 is compliant with the following safety regulations:

- UL 60950-1, 2nd Edition
- CAN/CSA C22.2 No. 60950-1-07, 2nd Edition
- EN 60950-1:2006/A11:2009/A1:2010/A12:2011/A2:2013
- IEC 60950-1:2005 (2nd Edition) + Am 1:2009 + Am 2:2013

### Emissions

GigaVUE-HC2 is compliant with the following emissions regulations:

- FCC Part 15, Class A
- VCCI Class A. Refer to [Class A Information Technology Equipment \(ITE\) on page 102](#).
- EN55022/CISPR-22 Class A
- Australia/New Zealand AS/NZS CISPR-22 Class A
- CE Mark EN 55022 Class A

## Class A Information Technology Equipment (ITE)

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

Translation of Statement for Class A VCCI-certified Equipment:

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.

## Immunity

GigaVUE-HC2 is compliant with the following immunity regulations:

- ETSI EN300 386 V1.3.2
- EN61000-4-2
- EN61000-4-3
- EN61000-4-4
- EN61000-4-5
- EN61000-4-6
- EN61000-3-2

## Environmental

GigaVUE-HC2 is compliant with the following environmental regulations:

- EU RoHS 6, EU directive 2011/65/EU
- NEBS Level 3. Refer to [E NEBS Level 3 Compliance on page 121](#).

## Security

GigaVUE-HC2 is compliant with the following security certifications:

- FIPS 140-2. Refer to “FIPS 140-2 Compliance” in the *GigaVUE-OS CLI User's Guide*.
- UC APL (option available). Refer to “UC APL Compliance” in the *GigaVUE-OS CLI User's Guide*.
- Common Criteria (option available). Refer to “Common Criteria” in the *GigaVUE-OS CLI User's Guide*.

---

## Warranty

Gigamon offers a range of premium support and extended services. For details regarding warranty, visit:

<https://www.gigamon.com/support-and-services/warranty>





## B Replacing a Control Card


---

This appendix describes how to replace a control card in a GigaVUE-HC2. Since there is only one control card, and it is internal, the unit must be powered down for any first time installation or remove and replacement.

Use this appendix for replacing an existing control card with the same control card.

Use the following appendix for replacing an existing control card with the GigaVUE-HC2 Control Card version 2 (HC2 v2): [C Upgrading to HC2 CCv2 on page 111](#).

The control card is located behind the fan unit, which must be removed to access the control card.



*Figure 0-1: Replacing a Control Card*

1. Log in to the serial console port on the node with the control card to be replaced and power it down gracefully with **reload halt** command, confirming your decision when prompted, as follows:

```

Node_A [100: standby] (config) # reload halt
Confirm reboot/halt? [no] yes
Halting system...
Node_A [100: standby] (config) #
System shutdown initiated -- logging off.
Gigamon GigaVUE H Series Chassis
INIT:Stopping pm: [ OK ]
Shutting down kernel logger: [ OK ]
Shutting down system logger: [ OK ]
Starting killall: Shutting down TFTP server: [ OK ]
[ OK ]
Sending all processes the TERM signal...
Sending all processes the KILL signal...
Remounting root filesystem in read-write mode:
Saving random seed:
Syncing hardware clock to system time
Running vpart script:
Unmounting file systems:
Remounting root filesystem in read-only mode:
Running vpart script:
Halting system...
sd 0:0:0:0: [sda] Stopping disk
Power down.

```

2. If the GigaVUE-HC2 is a slave node, from the SSH session to the VIP/Master IP address, check the cluster's operating parameters with the **show chassis** and **show cluster global** commands, as follows. Record the values shown for the **Cluster ID**, **Cluster Name**, and **Cluster Management IP** – for use when reconfiguring the node with its new control card.

```

Node_B [100: master] (config) # show chassis
  Box#  Hostname Config Oper Status HW Type      Product#  Serial# HW Rev SW Rev
-----
  2 *   Node_B   yes    up    HC2-Chassis  132-0098  80103   A3    2.7.0
  1    -       yes    down  HC2-Chassis  132-0098  80018   -     -
Node_B [100: master] (config) # show cluster global
Cluster ID:      100
Cluster name:    100
Management IP:  10.150.52.232/24
Cluster master IF: eth0
Cluster node count: 1

Node Status:
Node ID: 2 <--- (local node)
Host ID: ecde217e8354
Hostname: Node_B
Box-id: 2
Uptime: 0d 00h 23m 00s
CC1/CC2 Dynamic Sync status: in sync
Node Role: master
Node State: online
Node internal address: 169.254.126.51, port: 60102
Node external address: 10.150.52.10
Recv. Heartbeats from: -1
Send Heartbeats to: -1
Node_B [100: master] (config) #

```

3. In a stand-alone GigaVUE-HC2 use **show running-config** command, backup the entire system configuration to a text file, which can be used to reconfigure the new control card.
4. Power down the unit.
5. Remove the electrical connections from the unit.
6. Using a Phillips screw driver, remove the screws holding the fan unit at the back of the GigaVUE-HC2.
7. Remove the fan unit from the back of the unit.
8. Be sure to use an ESD grounding strap on your wrist or ankle before touching any cards.
9. Slide the control card out from the back side of the unit.
10. Slide the new control card into the GigaVUE-HC2.
11. Power-up the node.
12. Log on to the node over the console port.
13. Switch to **Configure** mode.
  - a. Type **en <Enter>** to switch to Enable mode.
  - b. Type **config t <Enter>** to switch to Configure mode.
14. Run the jump-start script with the following command if it does not appear automatically:  
`(config) # config jump-start`

15. Follow the jump-start script's prompts to reconfigure the node with the settings for the existing cluster you recorded in [Step 2](#), as follows.

```
Gigamon GigaVUE H Series Chassis
gigamon-0d04f1 login: admin
Gigamon GigaVUE H Series Chassis
GigaVUE-OS configuration wizard
Do you want to use the wizard for initial configuration? yes
Step 1: Hostname? [gigamon-0d04f1] Node_A
Step 2: Management interface? [eth0]
Step 3: Use DHCP on eth0 interface? no
Step 4: Use zeroconf on eth0 interface? [no]
Step 5: Primary IPv4 address and masklen? [0.0.0.0/0] 10.150.52.2/24
Step 6: Default gateway? 10.150.52.1
Step 7: Primary DNS server? 192.168.2.20
Step 8: Domain name? gigamon.com
Step 9: Enable IPv6? [yes]
Step 10: Enable IPv6 autoconfig (SLAAC) on eth0 interface? [no]
Step 11: Enable DHCPv6 on eth0 interface? [no]
Step 12: Enable secure cryptography? [no]
Step 13: Enable secure passwords? [no]
Step 14: Minimum password length? [8]
Step 15: Admin password?
Please enter a password. Password is a must.
Step 15: Admin password?
Step 15: Confirm admin password?
Step 16: Cluster enable? [no] yes
Step 17: Cluster interface? [eth2]
Step 18: Cluster id (Back-end may take time to proceed)? [default-cluster] 100
Step 19: Cluster name? [default-cluster] 100
Step 20: Cluster Master Preference (strongly recommend the default value)? [60]
Step 21: Cluster mgmt IP address and masklen? [0.0.0.0/0] 10.150.52.232/24

You have entered the following information:
 1. Hostname: Node_A
 2. Management interface: eth0
 3. Use DHCP on eth0 interface: no
 4. Use zeroconf on eth0 interface: no
 5. Primary IPv4 address and masklen: 10.150.52.2/24
 6. Default gateway: 10.150.52.1
 7. Primary DNS server: 192.168.2.20
 8. Domain name: gigamon.com
...

To change an answer, enter the step number to return to.
Otherwise hit <enter> to save changes and exit.

Choice:

Configuration changes saved.
To return to the wizard from the CLI, enter "configuration jump-start"
command from configure mode. Launching CLI...

*** Warning: This system is a member of a cluster. Shared configuration
must be changed on the cluster master.

Cluster ID:      100
Cluster name:    100
Management IP:  10.150.52.232/24
Cluster master IF: eth0
Cluster node count: 2
Local name:      Node_A
Local role:      standby
Local state:     online
Master address:  10.150.52.10 (ext) 169.254.126.51 (int)
Master state:    online
```

The serial number from the Node\_A chassis is still in the cluster's global configuration database. When the cluster detects **Node\_A** trying to join the cluster with a serial number it recognizes, it automatically configures the node with the box ID and packet distribution configuration associated with that serial number before the control card was replaced.

16. Next, run a series of **show** commands to verify that the node and cluster are operating as expected:

- a. From the VIP/Master IP address, run **show version box-id <id>** to make sure the correct images are loaded on the node. For example:

```
Node_B [100: master] (config) # show version box-id 1

=== Box-id : 1 (Role: standby) === Hostname: Node_A ===
Installed images:
Partition 1: (cur, next)
GigaVUE-H Series 2.7.0 #103-dev 2013-02-15 05:09:08 ppc gvcc2 build_master@BuildMaster:svn17810
Partition 2:
GigaVUE-H Series 2.7.0 #103-dev 2013-02-15 05:09:08 ppc gvcc2 build_master@BuildMaster:svn17810

U-Boot version: 2011.06.10
```

- b. From the VIP/Master IP address, run the **show cluster global** and **show chassis** commands to assure yourself that the cluster is stable and reliable. For example:

```
Node_B [100: master] (config) # show cluster global
Cluster ID: 100
Cluster name: 100
Management IP: 10.150.52.232/24
Cluster master IF: eth0
Cluster node count: 2

Node Status:
Node ID: 4
Host ID: 6c9834bec584
Hostname: Node_A
Box-id: 1
Uptime: 0d 00h 02m 55s
CC1/CC2 Dynamic Sync status: in sync
Node Role: standby
Node State: online
Node internal address: 169.254.46.92, port: 51612
Node external address: 10.150.52.2
Recv. Heartbeats from: 2
Send Heartbeats to: 2

Node_B [100: master] (config) # show chassis
Box# Hostname Config Oper Status HW Type Product# Serial # HW Rev SW Rev
-----
1 Node_A yes up HC2-Chassis 132-0098 80018 2.0 2.7.0
[100: master] (config) #
```



# C Upgrading to HC2 CCv2

---

This appendix describes how to upgrade an existing GigaVUE-HC2 control card to GigaVUE-HC2 Control Card version 2 (HC2 CCv2). Refer to the following sections for details:

- [Standalone Node on page 111](#)
- [Node in Out-of-Band Cluster on page 114](#)
- [Node in Inband Cluster on page 116](#)

**PREREQUISITE:** Install software version 4.6 or higher before upgrading the control card to HC2 CCv2.

**NOTE:** Be sure to use an ESD grouping strap on your wrist or ankle before touching any cards.

---

## Standalone Node

**NOTE:** The following procedure is for a standalone GigaVUE-HC2 node to upgrade the control card to HC2 CCv2. The software version on the HC2 CCv2 will be 4.6 or higher.

Before starting the procedure, backup the entire configuration on the node to a text file. This will later be used to reconfigure the HC2 CCv2.


```
(config) # configuration text generate active running upload <ftp | tftp | scp | sftp>://<upload URL>/<profilename.txt>
```

To upgrade a standalone GigaVUE-HC2 node to HC2 CCv2:

1. Log in to the serial console port on the node with the control card to be replaced and power it down gracefully with the **reload halt** command, confirming your decision when prompted, as follows:


```
Node_A [100: standby] (config) # reload halt
Confirm reboot/halt? [no] yes
Halting system...
Node_A [100: standby] (config) #
System shutdown initiated -- logging off.
Gigamon GigaVUE H Series Chassis
INIT:Stopping pm: [ OK ]
Shutting down kernel logger: [ OK ]
Shutting down system logger: [ OK ]
Starting killall: Shutting down TFTP server: [ OK ]
[ OK ]
Sending all processes the TERM signal...
Sending all processes the KILL signal...
Remounting root filesystem in read-write mode:
Saving random seed:
Syncing hardware clock to system time
Running vpart script:
Unmounting file systems:
Remounting root filesystem in read-only mode:
Running vpart script:
Halting system...
sd 0:0:0:0: [sda] Stopping disk
Power down.
```

2. Power down the standalone node by unplugging the power cable.
3. The control card is located below the fan tray unit, which must be removed to access the control card. Remove the two screws on the fan tray unit as shown in the following figure, then remove the fan tray unit.





4. Remove two lower screws as shown in the following figure.



5. Turn both latches outward as shown in the following figure to release the control card from the chassis.



6. Remove the existing control card.
7. Insert the new HC2 CCv2 control card.
8. Turn both latches inward.
9. Replace the two lower screws.
10. Insert the fan tray unit and replace the two screws on the fan tray unit.
11. Plug in the power cable.
12. When the node powers up, log on to it over the console port.
13. Switch to **Configure** mode.
  - a. Type **en <Enter>** to switch to Enable mode.
  - b. Type **config t <Enter>** to switch to Configure mode.
14. Run the jump-start script with the following command if it does not appear automatically:  
`(config) # config jump-start`
15. Follow the prompts for the jump-start script.
16. When the jump-start script has completed, run the following command to make sure the node has an IP address:  
`(config) # show interface eth0`

- Log into the node and run the **show card** command. Refer to the following sample output. Verify that the control card in the cc1 slot has the correct type: HC2-Main-Board-v2. Initially, the other cards will be down and only the control card will be operationally up.

```
(config) # show card
```

```
Box ID: 1
```

Slot	Config	Oper Status	HW Type	Product Code	Serial Num	HW Rev
cc1	yes	up	HC2-Main-Board-v2	132-00C2	1C20-0057	1.0-a0
1	yes	down	PRT-HC0-Q06	132-00BE	1BE0-01A2	B1-a3
2	yes	down	PRT-HC0-C02	132-00CR	1CR0-0034	3.0-a5
3	yes	down	SMT-HC0-X16	132-00BK	1BK0-001D	1.5-2

- Apply the previously saved configuration, using the following command:

```
(config) # configuration text fetch <http | https | ftp | tftp | scp | sftp>://<download URL>/<profilename.txt>
apply fail-continue verbose
```

- Verify that the information on the GigaVUE-HC2 with Control Card version 2 matches the previously saved configuration for chassis, cards, and traffic using the following CLI commands or others, depending on your configuration:

```
(config) # show version
(config) # show chassis
(config) # show cards
(config) # show map
(config) # show map stats all
```

## Node in Out-of-Band Cluster

The following procedure is for a GigaVUE-HC2 node in an out-of-band cluster to upgrade the control card to HC2 CCv2.

**NOTE:** The HC2 CCv2 requires software version 4.6 or higher.

Before starting this procedure, upgrade all the nodes in the cluster to 4.6 or higher.

Then use the **show chassis** command to record the GigaVUE-HC2 chassis box ID and the **show cluster config** command to record the cluster ID, cluster name, cluster master address vip, cluster master preference, and cluster interface.

To upgrade a GigaVUE-HC2 that is in an out-of-band cluster to HC2 CCv2:

- On the cluster master node, backup the entire configuration on the cluster to a text file.

```
(config) # configuration text generate active running upload <ftp | tftp | scp | sftp>://<upload URL>/
<profilename.txt>
```

- On the cluster master node, remove the configuration with the GigaVUE-HC2 node from the cluster database. The commands may vary depending on your configuration.

```
(config) # no map all
(config) # no gsop all
(config) # no vport all
(config) # no tunnel all
(config) # no gsgroup all
(config) # no stack alias <alias>
```

3. On the GigaVUE-HC2 node, issue the following commands:
 

```
(config) # no cluster enable
(config) # write memory
```
4. On the cluster master node, remove the GigaVUE-HC2 node information from the cluster database. Answer YES when prompted. This removes the GigaVUE-HC2 from the cluster.
 

```
(config) # no chassis box-id <box ID>
WARNING !! All the cards, ports, and traffic configuration will be lost.
Enter 'YES' to confirm this operation: YES
```
5. Upgrade the GigaVUE-HC2 to HC2 CCv2 by following the procedure for [Standalone Node on page 111](#) up to and including [Step 17](#). (Since the GigaVUE-HC2 has been removed from the cluster, it is a standalone node.)
6. When the GigaVUE-HC2 with HC2 CCv2 is back up, reinstate the cluster configuration including the cluster ID, cluster name, cluster master address vip, cluster master preference, and cluster interface, as well as the chassis box ID.
 

```
(config) # cluster id <cluster ID>
(config) # cluster name <cluster name>
(config) # cluster master address vip <cluster master vip>
(config) # cluster interface eth<x>
(config) # cluster master preference <preference number for master, standby, or normal>
```
7. On the cluster master node, configure chassis information on the GigaVUE-HC2 with HC2 CCv2, including the chassis box ID, serial number, and new node type.
 

```
(config) # chassis box-id <box ID> serial-num <serial number> type hc2-v2
```
8. On the GigaVUE-HC2 with HC2 CCv2 node, issue the following command for the node to rejoin the cluster:
 

```
(config) # cluster enable
```
9. When the GigaVUE-HC2 with HC2 CCv2 node is in the cluster, from the cluster master node apply the previously saved configuration:
 

```
(config) # configuration text fetch <http | https | ftp | tftp | scp | sftp>://<download URL>/<profilename.txt>
apply fail-continue verbose
```
10. Verify that the information on the cluster matches the previously saved configuration for chassis, cards, and traffic using the following CLI commands or others, depending on your configuration:
 

```
(config) # show version
(config) # show cluster global
(config) # show chassis
(config) # show cards
(config) # show map
(config) # show map stats all
```

## Node in Inband Cluster

The following procedure is for a GigaVUE-HC2 node in an inband cluster to upgrade the control card to HC2 CCv2.

**NOTE:** The HC2 CCv2 requires software version 4.6 or higher.

Before starting this procedure, upgrade all the nodes in the cluster to 4.6 or higher.

Then use the **show chassis** command to record the GigaVUE-HC2 chassis box ID and the **show cluster config** command to record the cluster ID, cluster name, cluster master address vip, cluster master preference, and cluster interface.

To upgrade a GigaVUE-HC2 that is in an inband cluster to HC2 CCv2:

1. On the cluster master node, backup the entire configuration on the cluster to a text file.

```
(config) # configuration text generate active running upload <ftp | tftp | scp | sftp>://<upload URL>/<filename.txt>
```

2. On the cluster master node, remove the configuration with the GigaVUE-HC2 node from the cluster database. The commands may vary depending on your configuration.

```
(config) # no map all
(config) # no gsop all
(config) # no vport all
(config) # no tunnel all
(config) # no gsgroup all
(config) # no stack alias <alias>
```

3. On the GigaVUE-HC2 node, issue the following commands:

```
(config) # no cluster enable
(config) # write memory
```

4. On the cluster master node, remove the GigaVUE-HC2 node information from the cluster database. Answer YES when prompted. This removes the GigaVUE-HC2 from the cluster.

```
(config) # no chassis box-id <box ID>
WARNING !! All the cards, ports, and traffic configuration will be lost.
Enter 'YES' to confirm this operation: YES
```

5. Upgrade the GigaVUE-HC2 to HC2 CCv2 by following the procedure for [Standalone Node on page 111](#) up to and including [Step 17](#). (Since the GigaVUE-HC2 has been removed from the cluster, it is a standalone node.)
6. When the GigaVUE-HC2 with HC2 CCv2 is back up, reinstate the original cluster configuration including the cluster ID, cluster name, cluster master address vip, cluster master preference, and cluster interface, as well as the chassis box ID. Then reinstate the interface configuration, chassis and card configuration, and GigaStream configuration used for the inband cluster stack-links.

The cluster configuration is as follows:

```
(config) # cluster id <cluster ID>
(config) # cluster name <cluster name>
(config) # cluster master address vip <cluster master vip>
(config) # cluster interface <interface>
(config) # cluster master preference <preference number for master, standby, or normal>
```

The interface configuration is as follows:

```
(config) # no interface eth1 zeroconf
(config) # no interface eth2 zeroconf
(config) # interface inband zeroconf
```

The chassis and card configuration is as follows:

```
(config) # chassis box-id <box ID>
(config) # card slot <slot number>
```

The GigaStream configuration is as follows:

```
(config) # port <box ID>/<slot number>/<stack ports> params admin enable
(config) # port <box ID>/<slot number>/<stack ports> type stack
(config) # gigastream alias <GigaStream alias> port-list <box ID>/<slot number>/<stack ports>
```

7. On the cluster master node, configure the GigaVUE-HC2 with HC2 CCv2 offline. The offline provisioning includes chassis, card, port, and GigaStream stack port configuration. The chassis configuration includes the chassis box ID, serial number, and new GigaVUE-HC2 with HC2 CCv2 node type of hc2-v2.

```
(config) # chassis box-id <box ID> serial-num <serial number> type hc2-v2
(config) # card slot <box ID>/<slot number> product-code <card product code for HC2 CCv2>
(config) # port <box ID>/<slot number>/<stack ports> params admin enable
(config) # port <box ID>/<slot number>/<stack ports> type stack
(config) # gigastream alias <GigaStream alias> port-list <box ID>/<slot number>/<stack ports>
```

**NOTE:** Step 6 configures the GigaVUE-HC2 with HC2 CCv2. Step 7 configures the cluster master node. The stack ports in Step 7 are the same as those in Step 6, under GigaStream configuration.

8. On the GigaVUE-HC2 with HC2 CCv2 node, issue the following command for the node to rejoin the cluster:

```
(config) # cluster enable
```

9. When the GigaVUE-HC2 with HC2 CCv2 node is in the cluster, from the cluster master node apply the previously saved configuration:

```
(config) # configuration text fetch <http | https | ftp | tftp | scp | sftp>://<download URL>/<filename.txt>
apply fail-continue verbose
```

10. Verify that the information on the cluster matches the previously saved configuration for chassis, cards, and traffic using the following CLI commands or others, depending on your configuration:


```
(config) # show version
(config) # show cluster global
(config) # show chassis
(config) # show cardss
(config) # show map
(config) # show map stats all
```



# D Console Port Signaling and Cabling

This appendix provides the pin-outs for the RJ45-to-RJ45 rollover cable and RJ45-to-DB-9 adapter provided with the GigaVUE-HC2 node for connections from the node's console port to a PC's COM port.

The following figure shows how to connect the RJ45-to-RJ45 rollover cable from the GigaVUE-HC2 node's console port to a COM port on a PC using the RJ45-to-DB-9 adapter.



The following table lists the pinouts for this connection.

Console Port from GigaVUE-HC2 RJ45 Jack	RJ45-to-RJ45 Rollover Cable		RJ45-to-DB-9 Terminal Adapter	Console Device on PC
Signal	RJ45 Pin	RJ45 Pin	DB-9 Pin	Signal
N/A	1	8	8	N/A
N/A	2	7	6	N/A
TxD	3	6	2	RxD
GND	4	5	5	GND
GND	5	4	5	GND
RxD	6	3	3	TxD
N/A	7	2	4	N/A
N/A	8	1	7	N/A



# E NEBS Level 3 Compliance

---

This appendix provides installation instructions for GigaVUE-HC2 Network Equipment-Building System (NEBS) Level 3 compliance. Refer to the following section for details.

- [Installation Instructions GigaVUE-HC2 on page 121](#)

---

## Installation Instructions GigaVUE-HC2

The following sections detail installation instructions for GigaVUE-HC2.

### Intrabuilding or Intra-connection

**WARNING:** The intra-building ports:

- BNC Coaxial PPS
- RJ45: PTP-1588, Management port, Console port
- PRT-HC0-X24
  - 1G/10G SFP/SFP+: X1 – X24
- PRT-HC0-Q06
  - 40G QSFP+: Q1 – Q6
- PRT-HC0-C02
  - 100G QSFP28: C1 - C2
- TAP-HC0-D25AC0
  - TAP SX/SR (50/125µm) 12 pairs: X1 – X24
- TAP-HC0-D25BC0
  - TAP SX/SR (62.5/125µm) 12 pairs: X1 – X24
- TAP-HC0-D35CC0
  - TAP LX/LR 12 pairs: X1 – X24
- TAP-HC0-G100C0
  - TAP 1G Copper 12 pairs: G1 – G24

- BPS-HC0-D25A4G
  - 1G/10G SFP/SFP+: X1 – X16
  - BPS SX/SR (50/125µm) 4 pairs: X17 – X24
- BPS-HC0-D25B4G
  - 1G/10G SFP/SFP+: X1 – X16
  - BPS SX/SR (62.5/125µm) 4 pairs: X17 – X24
- BPS-HC0-D35C4G
  - 1G/10G SFP/SFP+: X1 – X16
  - BPS LX/LR 4 pairs: X17 – X24
- SMT-HC0-X16
  - 1G/10G SFP/SFP+: X1 – X16

GigaVUE-HC2 equipment or subassembly are suitable for connection to intrabuilding or unexposed wiring or cabling only. The intra-building port(s) of the equipment or subassembly **MUST NOT** be metallically connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 2 or Type 4 ports as described in GR-1089-CORE, Issue 6) and require isolation from the exposed OSP cabling. The addition of Primary Protectors is not sufficient protection in order to connect these interfaces metallically to OSP wiring.

## Intrabuilding Ports (RJ45)

**WARNING:** The intrabuilding ports (RJ45) shall be connected to shielded and grounded cables at both ends.

## Class A2 Voltage Accessibility

The GigaVUE-HC2 shall be located in a restricted access location where only crafts personnel are allowed access.

## Class B Voltage Accessibility

The GigaVUE-HC2 shall be located in a restricted access location where only crafts personnel are allowed access.

## Equipment Grounding Systems

The GigaVUE-HC2 shall be installed and connected to the (CBN).

## Communication Equipment Grounding

The GigaVUE-HC2 is suitable for connection to the (Central Office and CPE).

## Bonding of Battery Return (BR) Input Terminals

The battery returns of the GigaVUE-HC2 shall be connected as (DC-I).

### Connections

- a. The GigaVUE-HC2 shall be grounded via a copper ground conductor #6 AWG for CPE installation.
- b. All bare grounding connection points to the GigaVUE-HC2 shall be cleaned and coated with an antioxidant solution before connections are made.
- c. All surfaces on the GigaVUE-HC2 that are unplated shall be brought to a bright finish and treated with an antioxidant solution before connections are made.
- d. All non-conductive surfaces on the GigaVUE-HC2 shall be removed from all threads and connection points to ensure electrical continuity.
- e. Multiple connectors shall not be secured by the same bolt assemblies.
- f. Unplated connection surfaces that are to be intentionally joined to form a bonding or grounding path shall be brought to a bright finish and then coated with an antioxidant before they are joined (electrical connections).
- g. Listing fastening hardware shall be compatible with materials being joined and shall preclude loosening deterioration, and electrochemical corrosion of the hardware and joined materials.
- h. Non-conductive coatings (such as paint, lacquer, and enamel) on the equipment to be bonded or grounded shall be removed from threads and other contact surfaces to assure electrical continuity.
- i. GigaVUE-HC2 utilizes a Spade width 0.32in/.81cm with a Standard Wire 12-16 (AWG) that utilizes 5in-lbs of torque to secure it to the frame and EUT. Only listed two-hole compression-type connectors shall be used in making connection to flat surfaces (such as bus bars, frames, racks, or cabinets). Torquing and bolts assembly requirements for securing the connector shall be as specified by the connector supplier.
- j. Anti-rotation devices, such as lock washers, will be used on grounding lugs to minimize the possibility of loosening from rotation during installation and maintenance activities.

### Input AC/DC Voltage

The GigaVUE-HC2 is capable of operating input 100-240V AC, 14-7A, 47-63Hz and/or -48V DC, 35-16A, 30A slow-blow.

### Commercial Power Ports

The manufacturer recommends that Surge Protection Device (SPD) is intended to be used with AC-power equipment. The SPD, if used, is installed at the AC power entrance (Refer to definition in the NEC).

## Maintenance

**CAUTION:** Remove all power sources before servicing. (TO COMPLETELY REMOVE POWER FROM THE UNIT, FIRST TURN OFF THE POWER SWITCH AND REMOVE BOTH POWER CABLES).

# F Additional Sources of Information

---

This appendix provides additional sources of information. Refer to the following sections for details:

- [Documentation on page 125](#)
- [Documentation Feedback on page 127](#)
- [Contacting Technical Support on page 127](#)
- [Contacting Sales on page 127](#)
- [The Gigamon Community on page 127](#)

---

## Documentation

[Table F-1](#) lists the documents that are provided for the various Gigamon products. You can download the PDF versions of these documents from the [Gigamon Customer Portal](#).

*Table F-1: Documentation Suite for Gigamon Products*

Document	Summary
<b>Hardware Installation Guides</b>	
<b>GigaVUE-HC1 Hardware Installation Guide</b>	Describes how to unpack, assemble, rack-mount, connect, and perform the initial configuration of GigaVUE-HC1 nodes. Also provides reference information for the GigaVUE-HC1 node, including specifications.
<b>GigaVUE-HC2 Hardware Installation Guide</b>	Describes how to unpack, assemble, rack-mount, connect, and perform the initial configuration of GigaVUE-HC2 nodes. Also provides reference information for the GigaVUE-HC2 node, including specifications.
<b>GigaVUE-HC3 Hardware Installation Guide</b>	Describes how to unpack, assemble, rack-mount, connect, and perform the initial configuration of GigaVUE-HC3 nodes. Also provides reference information for the GigaVUE-HC3 node, including specifications.
<b>GigaVUE TA Series Hardware Installation Guide</b>	Describes how to unpack, assemble, rack-mount, connect, and perform the initial configuration of GigaVUE-TA10, GigaVUE-TA40, GigaVUE-TA100, GigaVUE-TA100-CXP, and GigaVUE-TA200 nodes. Also provides reference information for these nodes, including specifications.

Document	Summary
<b>GigaVUE-OS Installation Guide on a White Box</b>	Describes how to install the GigaVUE-OS on a white box.
<b>Software Installation and Upgrade Guides</b>	
<b>GigaVUE-FM Installation and Upgrade Guide</b>	Provides instructions for installing GigaVUE-FM on VMware ESXi, MS Hyper-V, and KVM. Also, provides instructions to upgrade GigaVUE-FM.
<b>GigaVUE-OS Upgrade Guide</b>	Describes how to upgrade a GigaVUE H Series node or a GigaVUE TA Series node to the latest GigaVUE-OS.
<b>Administration Guide</b>	
<b>GigaVUE Administration Guide</b>	Describes how to use the GigaVUE-FM interface to administer the GigaVUE H Series and GigaVUE TA Series software.
<b>Configuration and Monitoring Guides</b>	
<b>GigaVUE-FM User's Guide</b>	Provides instructions for installing, deploying, and operating the GigaVUE <sup>®</sup> Fabric Manager (GigaVUE-FM).
<b>GigaVUE Cloud Suite for VMware Configuration Guide</b>	Provides instructions for installing, deploying, and operating the GigaVUE <sup>®</sup> Virtual Machine (GigaVUE-VM).
<b>GigaVUE Cloud Suite for AWS Configuration Guide</b>	
<b>GigaVUE Cloud Suite for Azure Configuration Guide</b>	Provides instructions on configuring the GigaVUE Cloud components and setting up traffic monitoring sessions for the respective Cloud platform.
<b>GigaVUE Cloud Suite for OpenStack Configuration Guide</b>	
<b>GigaVUE Cloud Suite for Kubernetes Container Configuration Guide</b>	
<b>GigaVUE Cloud Suite for AnyCloud Configuration Guide</b>	Describes how to deploy the GigaVUE Cloud solution in any of the cloud platforms available in the market.
<b>Reference Guides</b>	
<b>GigaVUE-OS CLI Reference Guide</b>	Describes how to use the CLI (Command Line Interface) to configure and operate the GigaVUE H Series and TA Series software.
<b>GigaVUE-OS Cabling Quick Reference Guide</b>	Provides guidelines to the different types of cables to be used to connect the Gigamon devices as well as connect Gigamon devices to third-party devices.
<b>GigaVUE-OS Compatibility and Interoperability Matrix</b>	Provides information about the compatibility and interoperability requirements for the Gigamon devices.
<b>REST API Getting Started Guide</b>	Introduction to the Application Program Interfaces (APIs) for GigaVUE-FM and provides an overview of these REST APIs, basic work flows, and use cases. The APIs are implemented with the Representational State Transfer (REST) architecture. (Deprecation announcement: This has not been updated since 5.4. The content will be merged into the GigaVUE-FM User's Guide in a subsequent release.)
<b>Release Notes</b>	
<b>GigaVUE Release Notes</b>	Summarizes new features and known issues in this release for GigaVUE-OS, GigaVUE-FM, and GigaVUE Cloud Suite.

---

## Documentation Feedback

To send feedback and report issues in our documentation, complete the short survey at the following link:

<https://www.surveymonkey.com/r/gigamondocumentationfeedback>

---

## Contacting Technical Support

Refer to <http://www.gigamon.com/support-and-services/contact-support> for Technical Support hours and contact information. You can also email Technical Support at [support@gigamon.com](mailto:support@gigamon.com).

---

## Contacting Sales

Table i shows how to reach the Sales Department at Gigamon.

*Table i: Sales Contact Information*

<b>Telephone</b>	+1 408.831.4025
<b>Sales</b>	<a href="mailto:inside.sales@gigamon.com">inside.sales@gigamon.com</a>

---

## The Gigamon Community

The [Gigamon Community](#) is a technical site where Gigamon users, partners, security and network professionals and Gigamon employees come together to share knowledge and expertise, ask questions, build their network and learn about best practices for Gigamon products.

Visit the Gigamon Community site to:

- Find knowledge base articles and documentation
- Ask and answer questions and learn best practices from other members.
- Join special-interest groups to have focused collaboration around a technology, use-case, vertical market or beta release
- Take online learning lessons and tutorials to broaden your knowledge of Gigamon products.
- Submit and vote on feature enhancements and share product feedback. (Customers only)
- Open support tickets (Customers only)
- Download the latest product updates and documentation (Customers only)

The Gigamon Community is a great way to get answers fast, learn from experts and collaborate directly with other members around your areas of interest.

**Register today at [community.gigamon.com](https://community.gigamon.com)**

Questions? Contact our Community team at [community.gigamon.com](https://community.gigamon.com)